

HP207

Roland Digital Piano
Owner's Manual

Roland®

WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

	CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN	
ATTENTION: RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR		
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.		



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS.

IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

WARNING - When using electric products, basic precautions should always be followed, including the following:

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



For the U.K.

IMPORTANT: THE WIRES IN THIS MAINS LEAD ARE COLOURED IN ACCORDANCE WITH THE FOLLOWING CODE.

BLUE: NEUTRAL
BROWN: LIVE

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:
The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK.
The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED.
Under no circumstances must either of the above wires be connected to the earth terminal of a three pin plug.

Before using this unit, carefully read the sections entitled: "IMPORTANT SAFETY INSTRUCTIONS," "USING THE UNIT SAFELY" (p. 6), and "Important Notes" (p. 9). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.

Copyright © 2006 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Introduction

Thank you, and congratulations on your choice of the HP207. To ensure that you obtain the maximum enjoyment and take full advantage of the HP207's functionality, please read this owner's manual carefully.

About the Manual

You should first read the "Before You Play" (p. 16) section of the owner's manual (this document). This explains how to connect the power cord and turn on the power. This owner's manual explains everything from basic operations that use the HP207's playback functions to more advanced operations, such as using the HP207 to record a song.

Conventions in this Manual

In order to explain the operations as clearly as possible, this manual uses the following conventions.

- Text enclosed in square brackets [] indicates the name of a button or a knob, such as the [Piano] button.
- Lines that begin with **NOTE** or an asterisk * are cautionary statements that you must be sure to read.
- The numbers of pages that you can turn to for additional, related information are given like this: (p. **).
- This document uses screen shots for explanatory purposes. Please be aware that the settings in these explanatory screen shots may not match the actual factory settings (Tone names, etc.).

Features of the HP207

Piano sounds with rich resonance and broad expressive range

The HP207 uses a stereo sampling piano sound generator that realistically reproduces even the sound of the hammers striking the strings, providing a faithful simulation of the sounds of a high-quality concert grand piano. With a maximum polyphony of 128 notes, it has ample capability even for performances that make extensive use of pedaling.

It contains not only piano sounds, but a total of more than 300 different sounds covering a wide range of musical styles. You can also play a drum set from the keyboard.

"Ivory feel" keyboard for realistic grand piano playing sensation

The unrivaled feel of the ivory and ebony traditionally used in the highest quality piano keyboards has been replicated using modern technology in the "ivory feel" keyboard. The white keys are a two-piece structure consisting of a base material and surface, providing a natural appearance as well as the ideal combination of strength and response.

The progressive hammer action II (PHA II) gives you a highly natural touch in which the low ranges have an appropriate weightiness and the high ranges have a light playing feel. In addition, the escapement mechanism that causes a distinctive sense of “click” when you play a note softly has also been faithfully replicated, giving the HP207 a high degree of playability.

To ensure sanitary conditions under extended use, long-lasting antibacterial processing has also been applied.

Gorgeous yet tasteful cabinet

The cabinet features a new design that projects the tasteful atmosphere of an acoustic piano when the cover of the operating panel is closed. Attention has been paid to giving the HP207 the aura of a quality musical instrument.

Versatile functionality you expect from a digital piano

Piano Designer

The HP207 rivals the sound and expressive power of a grand piano, with careful simulation of the changes in sound produced by opening or closing the grand piano lid, the subtle sounds of releasing a key, the sympathetic resonance between strings, and the sound of the damper pedal being pressed to move the damper away from the strings. These aspects of the sound can be customized to your taste.

Concert hall reverberation

In addition to high-quality reverberation effects, the HP207 provides a 3D Sound Control function, which reproduces the spatial depth of a full concert grand piano, and a Dynamics Sound Control function, which enhances the coherence and power of the sound.

You can also enjoy a special presence effect when performing with headphones.

Versatile functions to assist practicing, and built-in piano songs with accompaniment

The metronome function, a “3-track recorder,” and internal preset songs with orchestral accompaniment and an included score collection (containing sixty songs) make the HP207 an excellent choice for piano lessons.

Perform and save data

Data you perform using the recorder can be saved on a separately available floppy disk drive or USB memory device.

In addition to a floppy disk drive or USB memory, you can connect a commercially available USB-type CD drive and play back SMF music files, music CDs, or audio files. SMF music files from USB memory, floppy disk, or CD-ROM can also be saved in internal memory.

Contents

Introduction 2

About the Manual	2
Conventions in this Manual	2
Features of the HP207	2

USING THE UNIT SAFELY 6

Important Notes..... 9

Names of Things and What They Do..... 12

Front Panel	12
Bottom Panel (Rear)	14
Bottom Panel (Front Left)	15
Bottom Panel (Front Right).....	15

Before You Play 16

Getting Ready to Play	16
Connecting the Speaker Cable	16
Connecting the Pedal Cord	16
Connecting the Power Cord	16
Setting Up the Music Rest.....	17
Opening/Closing the Lid	17
Turning the Power On/Off	18
Adjusting the Sound's Volume and Brilliance	19
Adjusting the Brightness of the Display.....	19
About the Pedals	20
Listening through Headphones	21
Using the Headphone Hook	21
Using External Memory	22
Connecting USB Memory.....	22
Installing the Floppy Disk Drive	22
Using CD	22
Connecting a CD Drive	22

Listening to Demo Songs 23

Listening to the Tone Demo Songs	23
Listening to Piano Designer Demo Songs	25

Performing 26

Performing with a Variety of Sounds	26
Adjusting the piano sound to your taste (Piano Designer)	27
Adjusting the Keyboard Sensitivity (Key Touch)	30
Adding spatial depth to the sound (3D Sound Control)	31

Adding Liveliness to the Sound (Dynamics Sound Control)	32
Adding Reverberation to Sounds (Reverb Effect)	33
Changing the Depth of Reverb Effect	33
Adding a Variety Effects to the Sound (Effects)	34
Editing the effect settings	34
Adding a Spinning Sound to Organ Tones (Rotary Effect)	35
Changing the Key of the Keyboard (Key Transpose) .	36
Dividing the Keyboard for Two-person Performance (Twin Piano).....	38
Changing the way in which the sound is heard (Twin Piano mode)	39
Performing With Two Layered Tones (Dual Play)	40
Changing the Tone variations	41
Changing the Volume Balance for Dual Play.....	42
Performing with Different Tones in the Left and Right Sides of the Keyboard (Split Play)	43
Switching Tone Groups and Tone Variations.....	44
Changing the Keyboard's Split Point.....	45
Performing with the Metronome	46
Changing the Tempo	46
Changing the Beat	47
Changing the Volume	47
Sounding a Count to Keep your Timing Accurate	47

Playing Back Songs 48

Listening to Songs	48
Playing Back	
All Songs Continuously (All Song Play)	50
Listening to Each Part Separately	52
Determining the Volume of a Muted Part	53
Changing the Song Playback Volume.....	53
Adjusting the Volume of the Audio Files and Music CDs.....	53
Changing the Tempo of a Song	54
Playing Back at a fixed Tempo (Tempo Mute)	54
Changing the Key of the Song Playback (Playback Transpose).....	55
Minimizing the Center Sounds in the Playback (Center Cancel)	56

Recording 57

Recording Your Keyboard Performance	58
Recording Your Performance Separately for Each Hand.....	60
Recording Your Playing Along with a Song	63
Erasing Recorded Performances.....	66

Saving Your Performance.....67

Initializing the Memory	67
Saving and Copying	69
Saving the Songs You Record	70
Deleting a Song	72
Copying a Song	74

Various Settings.....76

Basic Operation in Function Mode	76
Tuning Settings	77
Matching the Pitch with Other Instruments (Master Tuning)	77
Equalizer Settings.....	78
Changing the Equalizer Settings (Equalizer)	78
Song playback settings	79
Determining the Parts that Sound (Part Mute)	79
Using the [Accomp] Button to Switch the Part to be Muted (Accomp Track) ...	79
Changing the Song Playback Method (Play Mode)	79
Metronome Setting	80
Changing the Sound of the Metronome (Metronome Sound)	80
Changing How the Metronome Marks the Beat (Metronome Pattern)	80
Sounding a Count Before the Melody Begins (Countdown)	80
Selecting the Count-down Sound (Countdown Sound)	80
Selecting the Part that Will Begin the Count-down (Countdown Part)	80
Keyboard Settings	81
Specifying What the Key Transpose will Affect (Transpose Mode)	81
Changing the Pitch of the Tone in Octave Steps (Octave Shift)	81
Changing the Velocity When the Key Touch is Set to "Fixed" (Fix Velocity)	81
Pedal Settings	81
Changing How the Pedal Effects Are Applied (Damper/Center/Left Pedal Part)	81
Changing How the Pedals Work (Center/Left Pedal Func)	81
MIDI Settings	82
Preventing Doubled Notes When Connected to a Sequencer (Local Control)	82
MIDI Transmit Channel Settings (MIDI Transmit Ch.)	82
Sending Recorded Performance Data to a MIDI Device (Composer MIDI Out)	82

Other Settings	83
Using the V-LINK Function (V-LINK)	83
Changing the USB Driver Settings (USB Driver) ..	84
Changing the External Memory Setting (Ext. Memory Mode) ...	84
Adjusting the Volume (Master Gain)	84
Changing How Grand Space is Applied (3D Mode)	84
Changing the Parts Assigned to the Track Buttons During SMF Playback (Track Assign).....	85
Switching On/Off the Display of Lyrics (Lyrics)...	85
Switching VIMA TUNES Recommended Tones (Recommended Tone)	85
Changing the Language Displayed in the Screen (Language)	85
Remembering the Settings (Memory Backup)	86
Restoring the Settings to the Factory Condition (Factory Reset)	86
Disabling the Buttons (Panel Lock).....	87

Connecting to Other Devices 88

Connecting to Audio Equipment	88
Connecting Speakers to the HP207 and Outputting Sounds.....	88
Playing Sounds of an Audio Device through the HP207	89
Connecting to MIDI Devices	90
Connecting a Computer to the HP207	90
Producing Sounds from a MIDI Sound Module by Playing the HP207	90
Connecting a Computer.....	91

Troubleshooting..... 92

Error Messages 96

Tone List..... 97

Internal Song List..... 104

Parameters Stored in Memory Backup..... 105

Music Files That the HP207 Can Use 106

MIDI Implementation Chart 107

Main Specifications..... 108

INDEX..... 110

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

⚠ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⚡ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ⚡ symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

Do not disassemble or modify

Do not disassemble or modify this device.



Do not repair or replace parts

Never attempt to repair this device or replace parts. If repair or part replacement should become necessary, you must contact your dealer or a Roland service center.



Do not use or store in the following types of locations

- Locations of extremely high temperature (such as in direct sunlight, near heating equipment, or on a device that generates heat)
- Near moisture (such as in a bathroom, near a sink, or on a wet floor) or in locations of high humidity
- Locations exposed to rain
- Locations of excessive dust
- Locations subject to heavy vibration



Do not place in an unstable location

Do not place this device on an unstable stand or a tilted surface. You must place it in a stable and level location.



Connect the power cord to an outlet of the correct voltage

You must connect the power cord to an AC outlet of the correct voltage as marked on the device.



⚠ WARNING

Use only the included power cord

You must use only the power cord included with the device. Do not use the included power cord with any other device.



Do not bend the power cord or place heavy objects on it

Do not bend the power cord excessively, or place heavy objects on the power cord. Doing so will damage the power cord, and may cause short circuits or faulty connections, possibly resulting in fire or electrical shock.



Do not share an outlet with an unreasonable number of other devices

Do not connect excessive numbers of electrical devices to a single power outlet. In particular, when using a power strip, exceeding the rated capacity (watts/amps) of the power strip may cause heat to be generated, possibly melting the cable.



Avoid extended use at high volume

This device, either by itself or used in conjunction with headphones, amps, and/or speakers, is capable of producing volume levels that can cause permanent hearing damage. If you experience impaired hearing or ringing in your ears, immediately stop using the device and consult a medical specialist.



Do not insert foreign objects

Never allow foreign objects (flammable objects, coins, wires, etc.) to enter this device. This can cause short circuits or other malfunctions.



⚠ WARNING

Turn off the power if an abnormality or malfunction occurs

If any of the following should occur, immediately turn off the power, disconnect the power cord from the AC outlet, and contact your dealer or a service center to have the device serviced.



- The power cord is damaged
- The device produces smoke or an unusual smell
- A foreign object enters the device, or liquid spills into the device
- The device becomes wet (by rain, etc.)
- An abnormality or malfunction occurs in the device

Do not allow children to use without supervision

In households with children, take particular care against tampering. If children are to use this device, they must be supervised or guided by an adult.



Do not drop or subject to strong impact

Do not drop this device or subject it to strong impact.



Do not use overseas

If you wish to use this device overseas, please contact your dealer or a service center.



Do not place containers of water on the device

Do not place containers of water (such as a flower vase) or drinks on the device. Nor should you place containers of insecticide, perfume, alcoholic liquids, nail polish, or spray cans on the device. Liquids that spill into the device may cause it to malfunction, and may cause short circuits or faulty operation.



⚠ CAUTION

Place in a well ventilated location

When using this device, ensure that it is placed in a well ventilated location.



Grasp the plug when connecting or disconnecting the power cord

When connecting or disconnecting the power cord to/from an AC outlet or the device itself, you must grasp the plug, not the cord.



Periodically wipe the dust off the power cord plug

From time to time, you should unplug the power cord from the AC outlet and use a dry cloth to wipe the dust off of it. You should also unplug the power cord from the AC outlet if you will not be using the device for an extended period of time. Dust or dirt that accumulates between the power cord plug and the AC outlet can cause a short circuit, possibly resulting in fire.



Manage cables for safety

Ensure that the connected cables are organized and managed in a safe manner. In particular, place the cables out of reach of children.



Do not stand or place heavy objects on this device

Do not stand on this device, or place heavy objects on it.



Do not connect or disconnect the power cord with wet hands

Do not connect or disconnect the power cord to the device or AC outlet while holding the power cord plug with wet hands.



Cautions when moving this device

When moving this device, please check the following cautions. Then, make sure that at least two persons work together in lifting and carrying the device, all the while making sure to keep it level. When doing so, be careful not to pinch your hands or drop the device on your feet.



- Check whether the knob bolts fastening the device to its stand have become loose. If they are loose, tighten them firmly.
- Disconnect the power cord.
- Disconnect external devices.
- Raise the adjuster of the stand.
- Close the lid.
- Fold down the music rest.

CAUTION

Unplug the power cord from the AC outlet before cleaning

Before you clean the device, turn off the power and unplug the power cord from the AC outlet.



If there is a possibility of lightning strike, disconnect the power cord from the AC outlet

If there is a possibility of lightning strike, immediately turn off the power and disconnect the power cord from the AC outlet.



Cautions when opening/closing the lid

Be careful when opening/closing the lid so you do not get your fingers pinched (p. 16). Adult supervision is recommended whenever small children use the unit.



Keep small items out of the reach of children

To prevent small items such as the following from being swallowed accidentally, keep them out of the reach of children.



- Included items
 - Screws for assembling the stand
 - Wing nut for headphone hook
 - Removed parts
 - Music rest attachment screws
 - Volume knob
 - Brilliance knob
-

Important Notes

In addition to the “USING THE UNIT SAFELY” listed on page 6, please observe the following cautions.

Power Supply

- Do not connect this device to the same electrical outlet as an inverter-controlled device such as a refrigerator, microwave oven, or air conditioner, or a device that contains an electric motor. Depending on how the other device is used, power supply noise could cause this device to malfunction or produce noise. If it is not practical to use a separate electrical outlet, please connect this device via a power supply noise filter.
- Before you make connections, you must switch off the power on all devices to prevent malfunction and/or speaker damage.
- When you turn off the power, the screen and indicators of this device will go dark, but this does not mean that the main power supply is completely disconnected. If you need to completely shut off the power supply, turn off the power switch of this device and then unplug it from the AC outlet. Connect this device to an AC outlet that is as close and accessible as possible.

Location

- If this device is placed near devices that contain large transformers, such as power amps, hum may be induced in this device. If this occurs, move this device farther away or change its orientation.
- If this device is operated near a television or radio, color distortion may be seen in the television screen or noise may be heard from the radio. If this occurs, move this device farther away.
- Keep your cell phone powered off or at a sufficient distance from this device. If a cell phone is nearby, noise may be heard when a call is received or initiated, or during conversation.
- Do not leave this device in direct sunlight, near devices that produce heat, or in a closed-up automobile. Do not allow illumination devices operated in close proximity (such as a piano light) or powerful spotlights to shine on the same location on this device for an extended time. This can cause deformation or color change.

- If you move this device between locations of radically different temperature or humidity, water droplets (condensation) may form inside the device. Using the device in this condition will cause malfunctions, so please allow several hours for the condensation to disappear before you use the device.
- Do not allow items made of rubber or vinyl to remain on top of this device for an extended time. This can cause deformation or color change.
- Do not leave objects on top of the keyboard. This can cause malfunctions such as failure to sound.
- Do not affix adhesive labels to this device. The exterior finish may be damaged when you remove the labels.

Care

- For everyday care, wipe with a soft dry cloth, or remove stubborn dirt using a tightly wrung-out cloth. If this device contains wooden components, wipe the entire area following the direction of the grain. The finish may be damaged if you continue strongly rubbing a single location.
- If water droplets should adhere to this device, immediately wipe them off using a soft dry cloth.
- Do not use solvents such as benzene, thinner, or alcohol, since these can cause deformation or color change.
- The pedals of this device are made of brass. Brass has a natural tendency to oxidize and become tarnished. If this occurs, use a commercially available metal polish.

Servicing

- If you return this device for servicing, the contents of memory may be lost. Please store important contents on USB memory, or make a note of the contents. We take utmost care to preserve the contents of memory when performing service, but there may be cases when the stored content cannot be recovered because the memory section has malfunctioned. Please be aware that we cannot accept responsibility for the recovery of lost memory content or for any consequences of such loss.


Other Cautions

- Stored content may be lost due to a malfunction of the device or because of inadvertent operation. You should back up important content on USB memory as a safeguard against such loss.
- We cannot accept responsibility for the recovery of any content lost from internal memory or USB memory, or for the consequences of such loss.
- Do not apply excessive force to the buttons, knobs, or input/output jacks, since this may cause malfunctions.
- Do not apply strong pressure to the display or strike it.
- When connecting or disconnecting cables, grasp the plug (not the cable) to prevent short circuits or broken connections.
- This device may produce a certain amount of heat, but this is not a malfunction.
- Please enjoy your music in ways that do not inconvenience other people nearby, and pay particular attention to the volume at nighttime. Using headphones will allow you to enjoy music without having to be concerned about others.
- When transporting or shipping this device, package it in an appropriate amount of cushioning material. Scratches, damage, or malfunctions may occur if you transport it without appropriate packaging.
- If using the music rest, do not apply excessive force to it.
- Some connection cables contain a resistor. Do not connect such cables to this device. Doing so may make the volume extremely low or inaudible. Please use connection cables not containing a resistor.
- Before opening or closing the keyboard lid, always make sure that no pets or other small animals are located on top of the instrument (in particular, they should be kept away from the keyboard and its lid). Otherwise, due to the structural design of this instrument, small pets or other animals could end up getting trapped inside it. If such a situation is encountered, you must immediately switch off the power and disconnect the power cord from the outlet. You should then consult with the retailer from whom the instrument was purchased, or contact the nearest Roland Service Center.

Floppy Disk Handling

(Using Optional Floppy Disk Drive)

- Floppy disks contain a plastic disk with a thin coating of magnetic storage medium. Microscopic precision is required to enable storage of large amounts of data on such a small surface area. To preserve their integrity, please observe the following when handling floppy disks:
 - Never touch the magnetic medium inside the disk.
 - Do not use or store floppy disks in dirty or dusty areas.
 - Do not subject floppy disks to temperature extremes (e.g., direct sunlight in an enclosed vehicle). Recommended temperature range: 10–50 degrees C (50–122 degrees F).
 - Do not expose floppy disks to strong magnetic fields, such as those generated by loudspeakers.
- Floppy disks have a “write protect” tab which can protect the disk from accidental erasure. It is recommended that the tab be kept in the PROTECT position, and moved to the WRITE position only when you wish to write new data onto the disk.



- The identification label should be firmly affixed to the disk. Should the label come loose while the disk is in the drive, it may be difficult to remove the disk.
- Store all disks in a safe place to avoid damaging them, and to protect them from dust, dirt, and other hazards. By using a dirty or dust-ridden disk, you risk damaging the disk, as well as causing the disk drive to malfunction.

USB Memory Handling

- When connecting USB memory, firmly insert it all the way in.
- Do not touch the pins of the USB memory connector, or allow them to become dirty.
- USB memory is made using high-precision electronic components, so please observe the following points when handling it.
 - To prevent damage from static electrical charges, discharge any static electricity that might be present in your body before handling USB memory.
 - Do not touch the terminals with your fingers or any metal object.
 - Do not bend or drop USB memory, or subject it to strong impact.
 - Do not leave USB memory in direct sunlight or in locations such as a closed-up automobile. (Storage temperature: 0–50 degrees C)
 - Do not allow USB memory to become wet.
 - Do not disassemble or modify USB memory.
- When connecting USB memory, position it horizontally with the external memory connector and insert it without using excessive force. The external memory connector may be damaged if you use excessive force when inserting USB memory.
- Do not insert anything other than USB memory (e.g., wire, coins, other types of device) into the external memory connector. Doing so will damage the external memory connector.
- Do not apply excessive force to the connected USB memory.
- If you will not be using USB memory for an extended period of time, close the USB memory cover.


Handling the CDs (CD-ROMs)

- When handling the discs, please observe the following.
 - Do not touch the encoded surface of the disc.
 - Do not use in dusty areas.
 - Do not leave the disc in direct sunlight or an enclosed vehicle.
- Avoid touching or scratching the shiny underside (encoded surface) of the disc. Damaged or dirty CD-ROM discs may not be read properly. Keep your discs clean using a commercially available CD cleaner.
- Keep the disc in the case.
- Do not keep the disc in the CD drive for a long time.
- Do not put a sticker on the label of the disc.
- Wipe the disc with a soft and dry cloth radially from inside to outside. Do not wipe along circumference.
- Do not use benzine, record cleaner spray or solvents of any kind.
- Do not bend the disc. Bending discs may prevent proper reading and writing of data, and may further result in malfunction.

* GS () is a registered trademark of Roland Corporation.

* XG lite () is a registered trademark of Yamaha Corporation.

Names of Things and What They Do



Front Panel

1 [Power] switch

Turns the power on/off (p. 18).

2 [Volume] knob

Adjusts the overall volume of the HP207 (p. 19).
If headphones are connected, this adjusts the headphone volume (p. 21).

3 [Brilliance] knob

Adjusts the tone brightness (p. 19).

4 [Effects] button

Lets you apply a variety of effects to the sound (p. 34).
You can also set a number of different functions when this button and the [3D] button are held down (p. 76).

5 [3D] button

Adds a sense of depth to the sound (p. 31).
By holding down this button and pressing the [Reverb] button to change the setting, you can make the sound more expressive (p. 32).

6 [Reverb] button

Adds reverberation similar to what you would hear when performing in a concert hall (p. 33).

7 [Transpose] button

Transposes the keyboard and/or song (p. 36).
By holding down this button and pressing the [Split] button, you can adjust the volume balance between the two sounds when using Dual play (p. 42).

8 [Split] button

Divides the keyboard into right-hand and left-hand areas, allowing you to play a different sound in each area (p. 43).

9 [Twin Piano] button

Divides the keyboard into two separate sections, allowing two people to perform in the same registers (p. 38).

10 Tone buttons


Here you can select the sound you'll hear when you play the keyboard (p. 26).

11 [Metronome/Count In] button

Turns the metronome on/off (p. 46).
This also lets you sound a count before the song begins, so that you can match the timing of your playing to the song (p. 47).

12 [Piano Designer] button

Here you can adjust the character of the piano sound to your taste by modifying parameters such as the sympathetic resonances of the piano strings (p. 27).



13 Display

This shows the sound name, song number, tempo, time signature, and the value of various settings.

14 [Tempo/Beat] (▲) button

Here you can adjust the tempo and time signature of the metronome (p. 46).

15 [Song] (▼) button

This lets you select the song to play back (p. 48).

16 [◀◀] (-) button

You can select the preceding song by pressing this button while the song select screen is displayed (p. 49). If you hold down this button while a song is playing, the song will be rewound.

Use this button to select variations of the sound you're playing on the keyboard (p. 26).

This button is also used to edit various values.

17 [▶▶] (+) button

You can select the next song by pressing this button while the song select screen is displayed (p. 49). If you hold down this button while a song is playing, the song will be fast-forwarded.

Use this button to select variations of the sound you're playing on the keyboard (p. 26).

This button is also used to edit various values.

18 [▶/■] (Play/Stop) button

Use this button to play/stop an internal preset song or a song you've recorded (p. 48).

This button is also used to begin recording your performance (p. 57).

19 [●] (Rec) button

This lets you record your own performance into the HP207 (p. 57).

20 Track buttons

You can use these buttons to play back or record your performance separately for each hand (p. 52, p. 60). The right-hand performance of internal preset songs is assigned to the [Right] button, the left-hand performance to the [Left] button, and the remaining parts of the performance to the [Accomp] button.

21 [Key Touch] button

This lets you adjust the touch sensitivity of the keyboard (p. 30).

You can listen to the demo songs by holding down this button and pressing the [File] button (p. 23).

22 [File] button


This lets you save a recorded song in internal memory or in USB memory (p. 70).

You can also copy songs between internal memory and USB memory (p. 74).

23 [Display Contrast] knob

This adjusts the brightness of the screen (p. 19).

Bottom Panel (Rear)



24 Input jacks (L/Mono, R)

Here you can connect an audio device or another electronic musical instrument, and listen to the connected device through the HP207's speakers (p. 89).

25 Output jacks (L/Mono, R)

You can connect an audio device or external powered speakers here to reproduce the HP207's sound (p. 88).


26 Pedal connector

Connect the pedal cord of the dedicated stand to this connector (p. 16).

27 Ac In (AC Inlet)

Connect the included power cord here (p. 16).

Bottom Panel (Front Left)



28 Phones jacks

Here you can connect headphones. The HP207 lets you use two sets of headphones simultaneously (p. 21).


30 USB connector

You can connect this to your computer for transferring performance data (p. 91).

29 MIDI Out/In connectors

You can connect these to external MIDI devices to transfer performance data (p. 90).

Bottom Panel (Front Right)



31 External Memory connector

Here you can connect USB memory, a floppy disk drive, or a CD drive, and play back stored songs (p. 48). You can also use USB memory to save a song you've recorded on the HP207 (p. 70).

By rotating the base you can neatly store the USB memory or USB cable.

** CD drives that draw their power from the USB connector cannot be used.*

32 Input jacks

Here you can connect an audio device or another electronic musical instrument, and listen to the connected device through the HP207's speakers (p. 89).


Before You Play

Getting Ready to Play

Connecting the Speaker Cable


Plug the speaker cable extending from the stand into the **SPEAKER** connector located at the rear of the HP207's bottom panel.

Pay attention to the shape of the speaker cable's connector, and insert it until you hear it click securely into place.




Connecting the Pedal Cord

Plug the pedal cord extending from the stand into the **Pedal** connector located at the rear of the HP207's bottom panel.




Connecting the Power Cord

1. Make sure that the [Power] switch located at the left side of the front panel is off (in the upward position).



2. Turn the [Volume] knob all the way toward the left to minimize the volume.
3. Connect the included power cord to the **AC INLET** located at the rear of the bottom panel.
4. Plug the other end of the power cord into an **AC outlet**.




NOTE You must use the power cord included with the HP207.

Setting Up the Music Rest

1. Grasping the music rest with both hands, lift it toward you until it's in the upright position.
2. Use the support on the back of the music rest to keep the stand in place.

The angle of the music rest can be set to any of three positions.




Folding down the music rest

Raise the support located on the back of the music rest, then gently fold down the music rest.

Using the music holders

You can use the holders to hold pages in place. When not using the holders, leave them folded down.




Removing the music rest

You can remove the music rest from the piano. This allows you to place a notebook computer on the piano.

Position the music rest so it's upright, then remove the three screws, as shown.

You can remove the screws using a coin.




NOTE Don't apply excessive force to the music rest.

NOTE Be careful not to lose the screws that you removed from the music rest, or put them where they might be swallowed by small children.

Opening/Closing the Lid

To open the lid, use both hands to lift it lightly, and slide it away from yourself.

To close the lid, pull it gently toward yourself, and lower it softly after it has been fully extended.



NOTE When opening and closing the lid, be careful not to let your fingers get caught. If small children will be using the HP207, adult supervision should be provided.

NOTE If you need to move the piano, make sure the lid is closed first to prevent accidents.


Turning the Power On/Off

NOTE


Once you've got everything connected properly, you can turn on the power using the following procedure. If you fail to perform these steps in the correct order, you risk causing a malfunction or damaging your speakers.

Turning the Power On

1. Turn the [Volume] knob all the way toward the left to minimize the volume.



2. Press the [Power] switch.



The power will turn on.

After a brief interval, you'll be able to produce sounds by playing the keyboard.


NOTE

Due to a circuitry protection feature, this unit requires a few moments after power is turned on before it is ready for normal operation.

3. Use the [Volume] knob to adjust the volume (p. 19).


Turning the Power Off

1. Turn the [Volume] knob all the way toward the left to minimize the volume.



2. Press the [Power] switch.

The screen goes blank and the power is turned off.



NOTE

If you need to turn off the power completely, first turn off the [Power] switch, then unplug the power cord from the power outlet. Refer to "Power Supply" (p. 9).

Adjusting the Sound's Volume and Brilliance

Here's how to adjust the volume of your keyboard playing or the playback volume of an internal song or USB memory song. If headphones are connected, use the [VOLUME] knob to adjust the headphone volume.



1. Turn the [Volume] knob to adjust the overall volume.

Adjust the volume while you play the keyboard to produce sound.

Turning the knob toward the right will increase the volume, and turning it toward the left will decrease the volume.


2. Turn the [Brilliance] knob to adjust the brightness of the sound.

Turning the knob toward the right will make the sound brighter, and turning it toward the left will make the sound more mellow.



Adjusting the Brightness of the Display

You can adjust the brightness of the HP207's display.




1. To adjust the brightness, turn the [Display Contrast] knob located at the right of the front panel.

Cautions Regarding the LCD Display

- You may notice something like vertical lines in the screen, but this is due to the characteristics of a liquid crystal display, and is not a malfunction. You can minimize this by using the [Display contrast] knob to adjust the brightness of the screen.
- The brightness may be affected by the temperature.

About the Pedals

The pedals perform the following operations. You'll use them mainly when playing piano.



Damper Pedal (right pedal)

Use this pedal to sustain the sound.

While this pedal is held down, notes will be sustained for an extended time even if you release your fingers from the keyboard.

The length of sustain will change subtly depending on how deeply you press the pedal.

When you press the damper pedal of an acoustic piano, a slight noise is heard when the damper frees the strings, and a richly spacious resonance is added by the strings that vibrate in sympathy with the strings of the notes you actually play. The HP207 replicates the sound created when the damper releases the string ("damper noise") and the sympathetic vibration ("damper resonance").



You can modify the sound of the damper releasing the string and the sound of the sympathetic vibration. Refer to the Piano Designer function (p. 27) settings "Damper Noise" and "Damper Resonance."

Sostenuto Pedal (center pedal)

The notes you are pressing when this pedal is depressed will be sustained.

Soft Pedal (left pedal)

This pedal is used to make the sound softer.

Playing with the soft pedal depressed produces a sound that is not as strong as when otherwise played with the equivalent strength. This is the same function as the left pedal of an acoustic piano.

The softness of the tone can be varied subtly by the depth to which you press the pedal.



You can switch the function of the sostenuto pedal. Refer to "Changing How the Pedals Work (Center/Left Pedal Func)" (p. 81).




If you disconnect the pedal cable from the HP207 while the power is turned on, the pedal effect will remain applied. You must connect or disconnect the pedal cable while the HP207's power is switched off.

About the Adjuster

If you feel that the pedal is unstable (for example if you've moved the HP207 to a different location), you can adjust the adjuster located on the bottom of the pedals as follows.


- Turn the adjuster to lower it until the adjuster is in firm contact with the floor. The pedal may be damaged if there is a gap between the adjuster and the floor. In particular, when you've placed the HP207 on carpet, you must turn the adjuster until it is pressing firmly against the floor.



Listening through Headphones

You can use headphones to enjoy the HP207 without disturbing those around you, such as at night. Since the HP207 has two headphone jacks, two people can also use headphones simultaneously.

If you're using only one set of headphones, you may connect them to either of the two headphone jacks.



1. Plug the headphones into the **PHONES** jack located at the left of the HP207's bottom panel.

If headphones are connected, no sound will be output from the HP207's speakers.

2. Use the HP207's **[VOLUME]** knob (p. 19) to adjust the headphone volume.

Cautions when Using Headphones


- To prevent damage to the cord's internal conductors, avoid rough handling. When using headphones, mainly try to handle either the plug or the headset.
- Your headphones may be damaged if the volume of a device is already turned up when you plug them in. Minimize the volume before you plug in the headphones.
- Excessive input will not only damage your hearing, but may also strain the headphones. Please enjoy music at an appropriate volume.
- Use headphones that have a stereo 1/4" phone plug.

Using the Headphone Hook

Whenever you are not using the headphones, you can hang them on the headphone hook of the HP207.

Attaching the Headphone Hook

1. Press and twist the headphone hook included with the HP207 into the hole in the bottom left of the HP207 (refer to the figure above).
2. Turn the headphone hook wing nut to secure the headphone hook.



NOTE

Do not hang anything other than headphones on the headphone hook. Doing so may damage the instrument or the hook.

MEMO

If headphones are connected, a headphone symbol is shown in the lower left of the screen.



Using External Memory

A song you've recorded on the HP207 can be saved by copying it to separately sold USB memory (p. 74).

You can also copy songs to a disk using a separately sold floppy disk drive.


Music data saved on USB memory can also be played back (p. 48).

NOTE

Use USB memory and floppy disk drive available from Roland. Proper operation cannot be guaranteed if other USB device is used.

Connecting USB Memory

1. Connect the USB memory to the External Memory connector.



Carefully insert the USB memory all the way in—until it is firmly in place.


MEMO

If you're using new USB memory, you'll need to initialize (format) it on the HP207. For details, refer to "Initializing the Memory" (p. 67).

Installing the Floppy Disk Drive

Attach the floppy disk drive as shown the figure, using the mounting holes on the HP207's bottom panel.

* For details of the attachment, refer to the owner's manual of the floppy disk drive.



Using CD

You can play back audio CDs and CD-ROMs containing saved SMF music files.

* You can also play songs on VIMA CD-ROMs (VIMA TUNES) sold by Roland.

Precautions Concerning Use of the CD

- You cannot play back CD-R/RW disks to which audio tracks have been added or CDs containing both audio tracks and data (CD Extra).
- The HP207 is capable of playing back only commercial CDs that conform the official standards—those that carry the "COMPACT DISC DIGITAL AUDIO" logo.
- The usability and sound quality of audio discs that incorporate copyright protection technology and other non-standard CDs cannot be guaranteed.
- For more detailed information on audio discs featuring copyright protection technology and other non-standard CDs, please consult the disc vendor.
- You cannot save songs and styles to CDs, and you cannot delete songs or styles recorded to CDs. Furthermore, you cannot format CDs.

Connecting a CD Drive

* CD drives that draw their power from the USB connector cannot be used.

1. Switch off the power to this instrument and the CD drive to be connected.
2. Connect the USB cable included with the CD drive to the External Memory connector on this instrument.
3. Turn on the power to this instrument.
4. Turn on the power to the connected CD drive.

NOTE

For information on how to perform the following CD-drive operations, refer to the owner's manual for the drive.

- Switching the power on and off
- Inserting and ejecting a CD

MEMO

A list of the CD drives that have been tested and found to be compatible is available on the Roland website.

<http://www.roland.com/>

Listening to Demo Songs

Listening to the Tone Demo Songs


Now, try listening to demo songs.

The HP207 comes with seven demo songs.

The six Tone buttons and the [Twin Piano] button are each assigned one demo song.

NOTE All rights reserved. Unauthorized use of this material for purposes other than private, personal enjoyment is a violation of applicable laws.

NOTE No MIDI data for the music that is played will be output.



1. Hold down the [Key Touch] button and press the [File] button.

The indicators for the Tone, [Twin Piano], and [Piano Designer] buttons flash.


The following appears in the display.



Button with tone demo	Demo content
[Piano]	Piano tone demo song
[E. Piano]	E.piano tone demo song
[Organ]	Organ tone demo song
[Strings]	Strings tone demo song
[Voice]	Demo song using Voice tones
[Others]	Demo song using Guitar tones
[Twin Piano]	Demo song using the Twin Piano function (p. 38)

When the following appears in the display

If there is the performance you recorded but have not yet saved, the following display will appear if you attempt to select a song.



You cannot play back a demo song if memory contains an unsaved song.

If you want to delete your performance and play back the demo song, press the [●] button. If you don't want to delete your performance, press the [▶/■] button. If you want to save your recorded performance, refer to "Saving the Songs You Record" (p. 70).

2. Press one of the six Tone buttons or the [Twin Piano] button.

The songs will play consecutively, starting with the demo song you selected. The button for the song currently being played back flashes on and off.

When playback of the last song is reached, playback continues by returning to the first song and playing that again.

The display will show the name of the currently playing demo song.



3. To stop playback, press the flashing button.

4. Press the [Key Touch] button or the [File] button to exit Demo mode.

The indicators return to their previous state.



If a button is not flashing, it means that it has no demo song.

Listening to Piano Designer Demo Songs

Here's how you can listen to the differences in various sounds created by the Piano Designer function (p. 27).

1. Hold down the [Key Touch] button and press the [File] button.

The indicators for the Tone, [Twin Piano], and [Piano Designer] buttons flash.
The following appears in the display.




NOTE

You can't play back the demo songs if your recorded performance has not been saved. Either press the [●] button to erase your performance (p. 24), or press [▶/■] button and save your recorded performance (p. 70).

2. Press the [Piano Designer] button.


Several of the tone buttons at the left and the [Piano Designer] button will flash.
The piano designer demo screen will appear.



3. Use the [▲] or [▼] buttons to select the demo you want to hear.

4. Press the flashing tone button.

The demo corresponding to the button you pressed will play.



By repeating steps 3 and 4, you can listen to other demos.

5. Press the [Piano Designer] button to access the demo song playback screen.

6. Press the [Key Touch] button or the [File] button to exit Demo mode.

The indicators return to their previous state.

Performing with a Variety of Sounds

The HP207 features over 300 different internal sounds, allowing you to enjoy performing with sounds suitable for many different types of music.

These onboard sounds are called “Tones.” The Tones are divided into six different groups, each of which is assigned to a different Tone button.

The Tone “Grand Piano 1” is selected when the instrument’s power is turned on.



1. Press a Tone button to select a tone group.

You’ll hear the Tone assigned to Tone number 1 in the selected Tone Group. Try fingering the keyboard.

The display will indicate the name and the number of the currently selected tone.



2. Use the [-] [+] buttons to select a sound from the tone group.

The Tone you’ve selected is heard when you finger the keyboard.

The next time you select this Tone button, you’ll hear the tone you selected here.



MEMO About the Tone name, refer to “Tone List” p. 97.

NOTE For some sounds, there are keys that do not produce sound.

Adjusting the piano sound to your taste (Piano Designer)


The HP207 provides a “Piano Designer” function that lets you customize the piano sound by adjusting aspects such as the sound of the sympathetically vibrating piano strings. You can also save a favorite sound you’ve created (p. 86).

1. Press the [Piano Designer] button.

The [Piano Designer] button will light, and the Piano Designer screen will appear. The Tone “Grand Piano 1” is selected.

2. Use the [-] [+] buttons to select the setting you want to adjust, and press the [▶/■] button to enter the setting screen.

There are four Piano Designer screens.



3. Use the [▲] [▼] buttons to select the item you want to adjust.

4. Use the [-] [+] buttons to adjust the setting.

The lid setting can also be adjusted using the [▲] [▼] buttons.

5. Press the [Piano Designer] button to return to the previous screen.

6. Repeat steps 3–6 to adjust the piano sound to your taste.

7. Press the [Piano Designer] button to return to the tone select screen.

Performing

Display	Parameter	Value	Description
Lid	Open/Close Lid	0–6	Adjusts the extent to which the lid of the grand piano is open. The sound will become more mellow as you close the lid of the piano in the screen. The sound will become brighter as you open the lid of the piano in the screen.
Keyboard	Key Touch	Fixed, Extra Light, Light, Medium, Heavy, Extra Heavy	Adjusts the touch sensitivity of the keyboard. If you select “Fixed,” notes will sound at a uniform volume regardless of how strongly you play the keyboard.
	Key Touch Offset	-10–0–9	This lets you make further detailed adjustments to the keyboard sensitivity as appropriate for the strength of your fingers. Higher settings will produce a heavier playing feel.
	Hammer Response	Off, 1–10	This adjusts the time from when you play a key until the piano sound is heard. Higher settings will produce slower response.
	Hammer Noise	-2–0– +2	This adjusts the sound produced when the hammer of an acoustic piano strikes the string. Higher settings will produce a louder sound of the hammer striking the string.
Tuning	Master Tuning	415.3–440.0–466.2 Hz	This adjusts the HP207s standard pitch (the pitch of the middle A note).
	Temperament	Equal, Just (Major), Just (Minor), Arabic, Kirnberger, Meantone, Pythagorean, Werkmeister	You can play classical styles such as Baroque using historic temperaments (tuning methods). Most modern songs are composed for and played in equal temperament, the most common tuning in use today. But at one time, there were a wide variety of other tuning systems in existence. By playing in the temperament that was in use when a composition was created, you can experience the sonorities of chords originally intended for that song. For details, refer to “Temperaments” p. 29.
	Tonic	C–B	When playing with tuning other than equal temperament, you need to specify the tonic note for tuning the song to be performed (that is, the note that corresponds to C for a major key or to A for a minor key). If you choose an equal temperament, there’s no need to select a tonic note.
	Stretched Tuning	Off, Preset, User (User: -50–0– +50)	This lets you specify the amount of “stretched tuning,” a tuning method specifically for pianos, in which the high range is tuned slightly sharper, and the low range is tuned slightly flatter. If you select “Preset,” a standard tuning curve created for the HP207 will be used. If you select “User,” you’ll be able to edit the stretched tuning yourself. Play the key whose pitch you want to adjust, then use the [-] [+] buttons to adjust its pitch. (If you adjust the “Preset” setting, the selection will change to “User.”)
Resonance	Damper Resonance	Off, 1–10	This adjusts the damper resonance of the acoustic piano sound (the sympathetic vibration produced in strings other than those actually played when you press the damper pedal). Higher settings will make the sympathetic vibration louder.
	Damper Noise	Off, 1–10	This adjusts the damper noise of the acoustic piano sound (the sound of the damper releasing the strings when you press the damper pedal).
	Duplex Scale	Off, 1–10	This adjusts the sympathetic vibrations of an acoustic piano’s Duplex Scale (p. 29). Higher settings will make the sympathetic vibration louder.
	String Resonance	Off, 1–10	This adjusts the string resonance of the acoustic piano sound (the sympathetic vibrations of strings for previously played notes that occur when you play another note). Higher settings will make the sympathetic vibration louder.
	Key Off Resonance	Off, 1–10	This adjusts sympathetic vibrations such as an acoustic piano’s key-off sound (the subtle sound that occurs when you release a note). Higher settings will make the sympathetic vibration louder.

Temperaments

Temperament	Qualities
Equal	In this tuning, each octave is divided into twelve equal steps. Every interval produces about the same amount of slight dissonance.
Just (Major)	This tuning eliminates ambiguities in the fifths and thirds. It is unsuited to playing melodies and cannot be transposed, but is capable of beautiful sonorities.
Just (Minor)	The Just tunings differ from major and minor keys. You can get the same effect with the minor scale as with the major scale.
Arabic	This tuning is suitable for the music of Arabia.
Kirnberger	This is an improvement of the Meantone and Just tunings that provides a high degree of freedom of modulation. Performances are possible in all keys (III).
Meantone	This scale makes some compromises in just intonation, enabling transposition to other keys.
Pythagorean	This tuning, devised by the philosopher Pythagoras, eliminates dissonance in fourths and fifths. Dissonance is produced by third-interval chords, but melodies are euphonious.
Werkmeister	This temperament combines the Meantone and Pythagorean tunings. Performances are possible in all keys (first technique, III).

What is the Duplex Scale?

The Duplex Scale is a system of sympathetically vibrating strings sometimes included in grand pianos.

These sympathetically vibrating strings are not struck directly with hammers, but sound by vibrating in sympathy with the vibrations of other strings. By resonating with the overtones, these strings add richness and brilliance to the sound. These sympathetic strings are added only to the high register above approximately C4. Since they do not have a damper (a mechanism that stops them from sounding), they will continue sounding even after you play a note and then release it to stop the sound of the string that was actually struck.

Saving the Piano Designer settings

The piano sound you create using Piano Designer will return to its original state when you turn off the power. If you want to keep the sound you created so that it will be preserved even when the power is off, execute the Memory Backup operation (p. 86) to save your settings.

Adjusting the Keyboard Sensitivity (Key Touch)

You can change the touch sensitivity, or response of the keys. You can adjust the keyboard touch as appropriate for the playing strength of the person who is performing.



1. Press the [Key Touch] button so it's flash.



2. Press the [-] or [+] buttons to select the keyboard touch.

Indicate	Button color	Description
Fixed	Orange	The sound plays at one set volume, regardless of the force used to play the keys.
Extra Light	Green	This setting produces the lightest keyboard touch.
Light	Green	You can achieve fortissimo (ff) play with a less forceful touch than usual, so the keyboard feels lighter. This setting makes it easy to play, even for children.
Medium	Dark	This sets the standard keyboard touch. You can play with the most natural touch. This is the closest to the touch of an acoustic piano.
Heavy	Red	You have to finger the keyboard more forcefully than usual in order to play fortissimo (ff), so the keyboard touch feels heavier. Dynamic fingering adds even more feeling to what you play.
Extra Heavy	Red	This setting produces the heaviest keyboard touch.

3. Press the [Key Touch] button so its illumination is turned off.

-  You can specify the volume at which the sound plays when the keyboard touch is set to "Fixed." Refer to "Changing the Velocity When the Key Touch is Set to "Fixed" (Fix Velocity)" p. 81.
-  You can also specify the keyboard touch from the Piano Designer screen. There you can also make more detailed settings for keyboard touch (p. 28).
-  You can use the Memory Backup function to store this setting in internal memory (p. 86).

Adding spatial depth to the sound (3D Sound Control)

The HP207 provides a “3D Sound Control” function, which creates the sense of spatial depth that you experience when playing a grand piano. This function adds the natural resonance and spaciousness that are characteristic of an acoustic piano.




1. Press the [3D] button so it's lit.

The 3D Sound Control function will be turned on, and the sound will have more spatial depth.

2. While holding down the [3D] button, use the [-] [+] buttons to adjust the spatial depth of the sound.

You can adjust the spatial depth over four levels.

Increasing the value will increase the spatial depth of the sound.



You can use the Memory Backup function to store this setting in internal memory (p. 86).



You can change the way in which the 3D Sound Control function is applied (p. 84).



If the Piano Designer screen is displayed, 3D Sound Control cannot be turned on/off.



3D Sound Control does not affect the sound from the Input jack or the sound of external devices connected to the MIDI Out connector.



When you turn Twin Piano on, 3D Sound Control will be turned off.

Turning off 3D Sound Control

1. Press the [3D] button so its light is turned off.

Adding Liveliness to the Sound (Dynamics Sound Control)

You can add liveliness to the sound to give it superb clarity and distinctness.



1. Hold down the [3D] button and press the [Reverb] button.

A screen will appear, allowing you to select the type of Dynamics Sound Control.



2. Use the [-] [+] buttons to select the desired sound control setting.



Indicate	Description
Off	Dynamics sound control is turned off.
Sharp	Creates a sound with boosted bass and treble.
Clear	Produces a sound with chords in the low registers that are clear and distinct.
Power	Creates a sound with boosted bass.

3. Press the [3D] button or the [Reverb] button.

You will return to the normal screen.

MEMO You can use the Memory Backup function to store this setting in internal memory (p. 86).

NOTE For some sounds, this may cause distortion.

NOTE Dynamics Sound Control does not affect the sound from the Input jack or the sound of external devices connected to the MIDI Out connector.

Adding Reverberation to Sounds (Reverb Effect)

You can apply a reverb effect to the notes you play on the keyboard. With the reverb effect, you obtain a pleasant reverberation, making it sound as if you were performing in a concert hall or similar space.



1. Press the [Reverb] button so it's lit.

Try fingering the keyboard.

The reverb effect is applied to the entire tone.

Turning Off the Reverb Effect

1. Press the [Reverb] button so its light is turned off.

NOTE Reverb will not be applied if Twin Piano is turned on with Twin Piano Mode "2" selected.

Changing the Depth of Reverb Effect

You can select from ten levels of depth for the reverb effect.

1. Hold down the [Reverb] button and press the [-] or [+] button.

The depth for the reverb effect appears in the display.



MEMO You can use the Memory Backup function to store this setting in internal memory (p. 86).

NOTE You cannot make separate reverb effect depth settings for each individual tone. The effect will be applied with the same depth to all tones.

NOTE This will not change the reverb depth for the song that is playing back.

Adding a Variety Effects to the Sound (Effects)

In addition to reverb, you can apply a variety of effects to the HP207's sounds. These are referred to as "effects." With the factory settings, an effect suitable for each tone is selected.

NOTE Effects may not be applied with some of sounds.



1. Press the [Effects] button so it's lit.

Try fingering the keyboard.

The effect is applied to the currently selected tone.



Some tones initially have effect applied. Selecting such a tone makes the [Effects] button light up automatically.

Turning Off the Effects




1. Press the [Effects] button so its light is turned off.

Editing the effect settings

Here's how to edit the settings of the effect.

1. Hold down the [Effects] button and press the [-] or [+] button.

The screen will show the effect parameters and their values.



- The most suitable type of effect is assigned for each tone.



Depending on settings such as 3D Sound Control, the effect may not be applied in some cases.

Adding a Spinning Sound to Organ Tones (Rotary Effect)

The Rotary effect is applied to some Organ tones you can select with the [Organ] button. When one of these tones is selected, you can use the [Effects] button to change the speed of the rotary effect.

What's the Rotary Effect?

What the rotary effect does is to add a "spinning" effect similar to the sound of an organ using a rotating speaker. In most rotary speakers, the high-frequency speaker and low-frequency speaker rotate at different speeds. The HP207 can simulate this complex type of modulation.

1. Press the [Effects] button to switch the speed of the rotary effect between rapid and slow rotation.

Pressing the [Effects] button toggles the rotary effect between fast and slow rotation.

If the [Effects] button is flashing rapidly, the rotary effect is being applied with the fast rotational speed. If the [Effects] button is flashing slowly, the rotary effect is being applied with the slow rotational speed.

Changing the Key of the Keyboard (Key Transpose)

The “Key Transpose” function lets you play a song at a different key. If you’re accompanying a singer, you can use the Transpose function to shift the pitch to a key that’s comfortable for the singer while you continue playing in the same familiar key (fingering).

You can also use this function to transpose the pitch of your playing without changing your fingering on the keyboard. For example, if the song is in a difficult key with numerous sharps (♯) or flats (♭), you can transpose to a key that’s easier for you to play.



On the HP207, you can transpose the pitch of just the keyboard, or the pitch of the keyboard and song together, or the pitch of just the song (Transpose Mode; p. 81).

When the HP207 is shipped from the factory, it is set so that the pitch of the keyboard and song will be transposed together (“Changing the Key of the Song Playback (Playback Transpose)” p. 55).

1. Hold down the [Transpose] button and press the key corresponding to the tonic of the desired key. (In this case, the note will not sound.)

The Key Transpose settings value continues to appear in the display while the [Transpose] button is held down.



With the [Transpose] button held down, you can change the value, even by pressing the [-] or [+] button.

The available range is -6–0– +5 (semitone steps).

If this is set to a value other than 0, the [Transpose] button will light.

If the transpose value is not “0,” you can use the [Transpose] button to turn the Transpose function on/off.

When you release the [Transpose] button, you return to the previous screen.



By holding down the [Transpose] button and pressing both the [-] and [+] buttons simultaneously, the setting returns to its original value (0).





The transpose setting will return to “0” when you select another song.

Example: Playing a Song in the Key of E Major After Transposition to C Major

Hold down the [Transpose] button and press the E key (since E is the tonic).

Counting from C as a reference point, one moves up four keys, including the black keys, to reach E, thus "+4" appears in the display.




If you switch songs or turn off the power, the Transpose setting will return to "0."

Dividing the Keyboard for Two-person Performance (Twin Piano)

You can divide the keyboard into left and right areas so that two people can play the same range of pitches.

This means that you'll be able to use the keyboard as though it were two separate pianos. For example, this provides a convenient way for one person to follow along with another person's performance to check it.



1. Press the [Twin Piano] button, getting its indicator to light.



When you turn Twin Piano on, the instrument will be in the following state.

- The keyboard will be divided into left and right areas, with “middle C” located in the center of each area.
- The left and right areas will have the same sound (Grand Piano 1).
- The right pedal will be the damper pedal for the right area, and the left pedal will be the damper pedal for the left area.
- If the Split function was on when you turned Twin Piano on, the Split function will be turned off.
- 3D Sound Control and the effect will be off.


Turning Off Twin Piano

1. Press the [Twin Piano] button so its illumination is turned off.

Changing the way in which the sound is heard (Twin Piano mode)

1. Hold down the [Twin Piano] button and press the [-] or [+] button.

You can choose one of the following ways in which the sound will be heard.



Indicate	Description
1	As usual, the sound will be heard from the right as you play toward the right of the keyboard, and from the left as you play toward the left.
2	Notes played in the right area will be heard from the right speaker, and notes played in the left area will be heard from the left speaker.

NOTE If you set Twin Piano mode to “2,” reverb will no longer be applied when you turn on Twin Piano mode.

NOTE For some sounds, the sound may not be split even if you set Twin Piano mode to “2.”

MEMO You can use the Memory Backup function to store this setting in internal memory (p. 86).

Performing With Two Layered Tones (Dual Play)

You can play two different sounds from a single key at the same time. This method of performance is called “Dual Play.”

As an example, let’s try layering piano and strings sounds.




1. Hold down the [Piano] button and press the [Strings] button.

The indicators for both buttons light.

Try fingering the keyboard. Both the piano and string sounds play.

Pressing two Tone buttons at the same time in this manner activates Dual Play.

Of the two selected tones, the one for the tone button at left is called “Tone 1” and the one for the button at right is called “Tone 2.”



Here, the piano tone is the Tone 1 and the strings tone is the Tone 2.

NOTE You can’t select Dual Play if you’ve turned on Split Performance or Twin Piano.

Turning Off Dual Play

1. Press any one of the Tone buttons.

Now you’ll hear only the tone of the button you pressed.

MEMO You can change the pitch of the Tone 2 an octave at a time. Refer to “Changing the Pitch of the Tone in Octave Steps (Octave Shift)” p. 81.

MEMO You can vary the volume-level balance of the two tones. Refer to “Changing the Volume Balance for Dual Play” p. 42.

MEMO If you press the pedals while using Dual Performance, the effect will be applied to both Tone 1 and Tone 2. However, you can change this setting so that the pedals will affect only one of the tones. Refer to “Changing How the Pedal Effects Are Applied (Damper/Center/Left Pedal Part)” p. 81.


NOTE Depending on the combination of the two tones, the effect may not be applied to Tone 2.

Changing the Tone variations

Changing the Tone 1

.....


1. Press the [-] or [+] button.



Changing the Tone 2


.....

1. Hold down the Tone button for the Tone 2 (the rightmost of the lit Tone buttons), and press the [-] or [+] button.




Changing the Volume Balance for Dual Play

You can change the volume balance of the Tones 1 and 2.



1. Hold down the [Transpose] button and press the [Split] button.


The current volume balance is shown.



2. Press the [-] or [+] button to change the volume balance.

The volume balance will change.

If you want to return to the original volume balance, press the [-] and [+] buttons simultaneously.



3. Press the [Transpose] button or [Split] button to return to the tone select screen.



You can use the Memory Backup function to store this setting in internal memory (p. 86).


Performing with Different Tones in the Left and Right Sides of the Keyboard (Split Play)

Performing with the keyboard divided at a certain key into a left side and a right side is called “Split Play,” and the point at which the keyboard is divided is called the “split point.”

In Split Play, you can have a different tone sound in the left and right sides.

When the instrument is turned on, the split point is set to “F # 3.” The split point key is included in the left side.

While in Split Play, a sound played in the right side is called a “right-hand tone,” and the sound played in the left side is called a “left-hand tone.”



As an example, here's how to play the tone of the [Piano] button as part of a Split performance.




1. Press the [Piano] button.

Now, the piano tone is selected.

2. Press the [Split] button, getting its indicator to light.

The keyboard will be divided into left and right sides.

The F # 3 key forms the division between the left and right sides of the keyboard.



The right-hand section of the keyboard plays piano tone, and the left-hand section plays “A. Bass+Cymbal” tone.

Turning Off Split Play

1. Press the [Split] button so its illumination is turned off.

The right-hand tone becomes the tone for the entire keyboard.




When you switch from Dual Play (p. 40) to Split Play, the Tone 1 used in Dual Play is selected as the right-hand one for Split Play.

Switching Tone Groups and Tone Variations


Changing the Right-hand Tone

1. Press the Tone button to choose a tone group.
2. Press the [-] or [+] button to select a variation tone.



Changing the Left-hand Tone

1. Hold down the [Split] button and press the Tone button to choose a tone group.
2. Hold down the [Split] button and press the [-] or [+] button to select a variation tone.




You can change the pitch of the left-hand tone an octave at a time. Refer to "Changing the Pitch of the Tone in Octave Steps (Octave Shift)" p. 81.

Changing the Keyboard's Split Point

You can change the split point (the key at which the keyboard is divided).

The split point can be set to any value from B1 through B6.

This is set to "F # 3" at the factory settings.



1. Hold down the [Split] button and press a key set as the split point.

The key you pressed becomes the split point, and appears in the display.



The key being used as the split point belongs to the left-hand section of the keyboard.

The previous display will reappear when you release the [Split] button.

The name of the left-hand tone is displayed while you hold down the [Split] button.




You can use the Memory Backup function to store this setting in internal memory (p. 86).

Performing with the Metronome

You can perform while the metronome sounds. The HP207 provides a versatile Metronome function.

You can adjust the volume or time signature of the metronome, and change the way that beats are marked. If a song is playing, the metronome will sound at the tempo and time signature of that song.



1. Press the [Metronome] button so it's lit.

The metronome screen will appear, and the metronome will be heard.

The [Metronome] button flashes in red and green in time with the beat selected at that time. The indicator lights in red on the downbeats, and in green on weak beats.



MEMO You can change the sound of the metronome (p. 80).

Stopping the Metronome Function

1. Press the [Metronome] button so its light is turned off.

Changing the Tempo

1. Press the [Tempo/Beat] button several times so it's lit in red.

The tempo is displayed.




2. Press the [-] or [+] button to adjust the tempo.

The tempo is set in terms of the value of a quarter note, with possible values ranging from 10 up to 500.

Changing the Beat

1. Press the [Tempo/Beat] button several times so it's lit in green.

The beat is displayed.



2. Press the [-] or [+] button to select the beat.

With the "0/4" setting, only weak beats will be sounded.



You can change the way in which the metronome will distinguish the beats. For details, refer to "Changing How the Metronome Marks the Beat (Metronome Pattern)" p. 80.



When you play back a song, the metronome's beat will be set to the beat of that song.




You can't change the metronome's beat while a song is playing.

Changing the Volume

The volume of the metronome can be adjusted, with 11 volume levels available.

1. While holding down the [Metronome] button, press the [-] or [+] button.

The display will indicate the metronome volume.



This is set to "5" when the instrument is turned on.



When the metronome volume is set to "0," the metronome sound does not play.

Sounding a Count to Keep your Timing Accurate

A "count-in" is a count that is sounded before the song begins to play.

If you're playing along with a song, you can sound a count to make it easier to synchronize your own playing with the song.

1. While holding down the [Metronome] button, press the [▶/■] button.

A two-measure count sounds before the song plays.



A "count-down" is a count that is sounded at the end of the song's introduction (before you begin playing the keyboard) (p. 80).

Playing Back Songs

Listening to Songs

Here's how to listen to the internal preset songs, songs from internal memory, or songs from USB memory (sold separately).

The HP207 provides seventy piano songs as internal preset songs.




You can listen to songs from floppy disk by using a separately sold floppy disk drive. By using a commercially-available CD drive, you can listen to SMF data or VIMA CD-ROMs (VIMA TUNES) on a CD-ROM, or listen to music CDs.

Selecting a Song

1. Press the [Song] button so it's lit.

The following appears in the display.



Songs can be selected from internal memory only if the song you want to hear has already been saved in internal memory. For details, refer to "Copying a Song" (p. 74). To select a song from USB memory (sold separately), connect the USB memory containing the desired song to the external memory connector, then press the Song button (p. 22).

2. Press the [-] or [+] button to select the song.

If an internal preset song is selected, the screen will indicate "Preset."

Songs in internal memory are indicated as "Internal," songs in USB memory as "External," songs on floppy disk as "Disk," songs on CD-ROM as "CD," and songs on a music CD as "Music CD."

To select a song that's inside a folder, select the folder and press the [▶/■] button.

To exit the folder, select "Up" and press the [▶/■] button.

Playing the Song

3. Press the [▶/■] button.

The selected song will play. The selected song is played to the end, and then playback stops.

To stop playback, press the [▶/■] button once more.

The next time you press the [▶/■] button, playback will resume from the point at which you stopped.



If you play back song data that contains lyrics, the lyrics will be shown in the screen. You can specify whether the lyrics will be shown (p. 85).


Fast-forward and rewind

- Press the [▶▶] button to move to the beginning of the next song.
- Press the [◀◀] button to move to the beginning of the currently selected song. If you're already at the beginning of the song, you will move to the beginning of the preceding song.
- If you hold down the [▶▶] button while a song is playing, the song will fast-forward.
- If you hold down the [◀◀] button while a song is playing, the song will rewind.

About the Song Select Screen

The song select screen shows the following information.

New Song to record




Song in External Memory



You can play back audio files from external memory (p. 56). The HP207 supports 16-bit linear, 44.1 kHz audio files in .WAV format. If a CD drive (commercially available) is connected, you can also play back music CDs.




Song in Internal Memory



Internal Preset Song



Song Number



By holding down the [Song] button and pressing the [-] [+] buttons, you can quickly select the first song in each song group; e.g., "the first song in external memory," "the first song in internal memory," or "the first internal preset song."




If no songs are saved in internal memory, you won't be able to select "internal memory." Similarly, you won't be able to select "external memory" if no songs are saved in USB memory, or if USB memory is not connected.



About the name of the internal song, refer to "Internal Song List" (p. 104).

Playing Back All Songs Continuously (All Song Play)


The internal songs and the songs in internal memory can be played repeatedly in succession.




Making preparations for continuous playback

1. Hold down the [Effects] button and press the [3D] button.


The song select screen shows the following information.




2. Use the [▲] [▼] buttons to select "Play Mode."



3. Press the [▶/■] button to enter the setting screen.



4. Press the [-] or [+] button to select "All Song."



5. Press the [Piano Designer] button twice.

You will return to the tone select screen.

Specifying the First Song

6. Press the [Song] button so it's lit.


7. Press the [-] or [+] button to select the song.

8. Press the [▶/■] button so it's flash.

The songs will play successively, starting with the selected song.

When the last song finishes playing, playback will return to the first song and then continue.

If you're playing in All Song Play mode, a symbol to indicate this is shown in the upper right of the screen.



The songs in internal memory will play consecutively if an internal memory song is selected, and the songs in USB memory will play consecutively if a USB memory song is selected.

To Stop Playback

9. Press the [▶/■] button so its illumination is turned off.

The next time you press the [▶/■] button, playback will resume from the point at which you stopped.



You can use the Memory Backup function to store this setting in internal memory (p. 86).



By holding down the [Song] button and pressing the [▶/■] button, you can play all songs regardless of the Song Play mode.


Listening to Each Part Separately

With the internal songs, you can select the performance part that is to be played back. You can also practice each hand separately while playing along with the song.



The performance data is assigned to the Track buttons as shown below.

The left-hand performance is assigned to the Track [Left] button, the right-hand performance is assigned to the Track [Right] button, and other performance is assigned to the Track [Accomp] button. "Tracks" are areas in which music data is held, and buttons [Left], [Right], and [Accomp] are referred to as the "track buttons."



1. Select the song that you want to play (p. 48).

2. Press the [▶/■] button to play the song.

3. Select the part that you don't want to play back.

Press the Track [Left] button, Track [Right] button, or the Track [Accomp] button.

The button you pressed will go out, and the corresponding part will no longer be heard.

Temporarily silencing a specific part in this way is called "muting."



For example, if you want to practice the right-hand part, press the Track [Right] button so its illumination is turned off. When you play back the song, the right-hand part will not play.

If you again press the button you selected in step 3, so the button is lit, the sound of that part will be heard.



Mute settings will be cleared when you switch songs.

Determining the Volume of a Muted Part


Here's how to adjust the volume that a part will have after you've pressed a track button to mute the playback while playing back a song.

The HP207 lets you play back a specific part at a reduced volume so you can use that part as a "guide" for your own playing.

1. **Hold down a track button and use the [-] [+] buttons to specify the volume that the track will have when its playback is muted.**

The volume for when the track is muted will be shown while you hold down the track button.

The track mute volume can be set to any value from 0 to 80.



When you turn off the power, the track mute volume will be reset to "0."

Changing the Song Playback Volume

Here's how to change the volume at which the song will play.

When you're practicing along with a song, this allows you to adjust the volume balance between your keyboard performance and the song playback.

1. **While holding down the [▶/■] button, press the [-] [+] buttons.**

The song playback volume is displayed while you hold down the [▶/■] button.

The playback volume can be set to any value from 0 to 127.



When you turn off the power, the song playback volume will revert to "127."

Adjusting the Volume of the Audio Files and Music CDs

When you select an audio file or a song from music CD, it will play back at a separately-specified volume setting.

1. **While holding down the [▶/■] button, press the [-] [+] buttons.**



When you turn off the power, this playback volume will return to a setting of "64."

Changing the Tempo of a Song

You can change the tempo at which the song plays.
When you're practicing one of the internal songs, slowing down the tempo of the playback can make it easier to play along with a difficult song.

- 1. Press the [Tempo/Beat] button several times so it's lit in red.
- 2. Use the [-] [+] buttons to change the tempo.

Playing Back at a fixed Tempo (Tempo Mute)


Some of the internal preset songs have a tempo that varies during the song.
Here's how you can make these songs play back at a fixed, unchanging tempo.

- 1. While holding down the [Tempo/Beat] button, use the [-] [+] buttons to change the setting.



Value	Explanation
On	The tempo changes recorded in the song will be ignored, and the song will play at a fixed tempo.
Off	The song will play back according to the tempo changes recorded in the song.

If you turn Tempo Mute on, the tempo indication in the screen will be highlighted.



When you switch songs, the Tempo Mute function will revert to the "off" setting.

Changing the Key of the Song Playback (Playback Transpose)

The “Playback Transpose” function lets you change the key of the song playback.



1. Play back the song that you want to hear or play along with (p. 48).
2. While holding down the [Transpose] button, use the [-] [+] buttons to adjust the pitch.

The pitch of the song will change in semitone steps.

The Playback Transpose setting is shown while you hold down the [Transpose] button.

The range is -6–0–5 (semitone steps).

If this is set to a value other than 0, the [Transpose] button will light.

If the transpose value is other than “0,” you can use the [Transpose] button to turn the Playback Transpose function on/off.



If you hold down the [Transpose] button and press both the [-] and [+] buttons simultaneously, this setting will return to its original value (0).



The Playback Transpose function won’t be applied if the Transpose Mode (p. 81) is set to “Keyboard.”



If you’ve selected a song from a music CD or an audio file, using Playback Transpose may affect the tonal character.



The transpose setting will return to “0” when you select another song.

Minimizing the Center Sounds in the Playback (Center Cancel)

When playing back a commercially available CD or audio file, you can minimize the sounds that are located in the center (such as vocals).



1. Play back an audio file or music CD (p. 48).
2. Press the [Right] track button so its illumination is turned off.

The melody or vocal sound will be minimized.

NOTE For some songs, the sounds in the center may not be entirely eliminated.

Defeating the Center Cancel function

1. Press the [Right] track button so it's lit.

NOTE For some songs, using the Center Cancel function may affect the tonal character.

NOTE The Center Cancel setting will be cancelled when you select another song.

About Audio Files

Audio files of the following format can be played

- File extension is ".wav"
- 16-bit linear
- 44.1 kHz sampling rate

The following functions cannot be used for audio file playback.

- 3D Sound Control (p. 31)
- Reverb (p. 33)
- Effects (p. 34)
- Tempo change (p. 54)
- Save to internal memory (p. 71)
- Recording (p. 57)
- Play back (mute) individual parts (p. 52)

* If you execute an operation such as Save while an audio file is playing, the song may stop before the end.

Recording

You can easily record your performances.


By playing back your performance you can listen to yourself playing, or use the keyboard to play the melody along with the song you recorded.

You can perform the following types of recording.

Recording just your own keyboard performance	→ "Recording Your Keyboard Performance" (p. 58)
Selecting a track button and recording	→ "Recording Your Performance Separately for Each Hand" (p. 60)
Re-recording	→ "Recording Your Performance Separately for Each Hand" (p. 60)
Recording along with an internal song	→ "Recording Your Playing Along with a Song" (p. 63)


Memo

With second or later recordings, the previously recorded song is erased as the new material is recorded. When recording a new performance, it is probably a good idea to erase the previously recorded performance first (p. 66).



If the Following Display Appears

A display like the one shown below will appear if you attempt to select another song or record a new song when there is a recorded performance that has not been saved.



You can't play back another song if there is an unsaved (user) song.

If it is OK to delete the song, press the [●] button.

If you don't want to delete the song, press the [▶/■] button and save your song to internal memory or USB memory (p. 70).


Recording Your Keyboard Performance

Here's how to record just your own keyboard performance without using an internal song.



Performance Settings

1. Press the [Song] button so it's lit.
2. Press the [-] button a number of times, until "New Song" appears in the display.



Alternatively, you can get "New Song" to be displayed by holding down the [Song] button and pressing the [●] button.

3. Select the Tone to be played (p. 26).
4. If necessary, sound the metronome.
Press the [Metronome] button (p. 46).
While listening to the metronome, adjust the song tempo (p. 46) and the beat (p. 47) as desired.

Settings for Recording

5. Press the [●] button.

The [●] button lights, the [▶/■] button begins flashing, and the HP207 is put into recording standby.

If you decide not to record, press the [●] button once again.

Starting Recording

6. Press the [▶/■] button or play the keyboard.

After two measures of count sound, recording begins.

Recording starts when you start playing the keyboard (without pressing the [▶/■] button). In this case, a count is not sounded.

When recording begins, the [●] button and [▶/■] button will light.



During the count-in, the count measure is indicated in the lower right of the display as "-2" then "-1."

Stopping Recording

7. Press the [▶/■] button.

Recording will stop.

Listening to the Recorded Performance

8. In the song select screen, press the [◀◀] button.

You will return to the beginning of the performance you recorded.

9. Press the [▶/■] button.

The recorded performance will play back.



If you press the [▶/■] button while the metronome is sounding, there will be a two-measure count ("count-in") before playback begins.

10. Press the [▶/■] button once again to stop playback.



The recorded performance will disappear when you turn off the power. If you want to keep the performance you recorded, you must save it in internal memory or USB memory. Refer to "Saving the Songs You Record" (p. 70).



If you have not saved the performance you recorded, you won't be able to play back another song. You'll have to erase (p. 66) or save (p. 70) the performance before playing back another song.

Recording Your Performance Separately for Each Hand

The HP207’s recorder has three track buttons. You can record the performance of each hand separately to different track buttons (for example, the left-hand performance to the [Left] button and the right-hand performance to the [Right] button), or you can re-record just a specific track of a previously recorded performance.

How the track buttons correspond to the recorded performances

The recorded performances are assigned to the track buttons as follows.

● Split performance (p. 43)

Track button	Recorded performance
[Right] button	Right-hand tone
[Left] button	Left-hand tone

● Normal performance (the entire keyboard plays a single tone), Dual performance

- When you record with just one recording track specified
The performance will be recorded on the specified track.
- When you record with multiple recording tracks specified
Recording will take place in this order of priority: [Right] button → [Left] button → [Accomp] button.



Settings for recording

1. Press the [Song] button so it’s lit.
2. Press the [-] button a number of times, until “New Song” appears in the display.

3. Press the [●] button.

The [●] button will light, the [►/■] button indicator will flash, and the HP207 will enter recording standby mode.

If you decide not to record, press the [●] button once again.

The button of the track to be recorded will flash.

4. Press the button of each track you don't want to record, turning off its illumination.

MEMO You can record to only one track button at a time.

Recording**5. Press the [►/■] button.**

After two measures of count sound, recording begins.

Recording starts when you start playing the keyboard (without pressing the [►/■] button). In this case, a count is not sounded.

When recording begins, the [●] button and [►/■] button will light.


MEMO During the count-in, the count measure is indicated in the lower right of the display as "-2" then "-1."

6. To stop recording, press the [►/■] button.**Recording an additional part****7. In the song select screen, press the [◀◀] button.**

You will return to the beginning of the recorded performance.

8. Press the [●] button.


The following screen will appear.



If you want to erase the previously recorded performance and re-record a new performance, press the [►/■] button.

9. If you want to record another track, press the [●] button.

The following screen will appear.



10. Press the button of the track you want to record, making it flash.

NOTE If you select a previously recorded track, that track will be overwritten by the newly recorded performance, and the previously recorded performance will be lost.

The [●] button will light, the [►/■] button indicator will flash, and the HP207 will enter recording standby mode.

If you decide not to record, press the [●] button once again.

11. Press the [►/■] button.

After two measures of count sound, recording begins.

Recording starts when you start playing the keyboard (without pressing the [►/■] button). In this case, a count is not sounded.

When recording begins, the [●] button and [►/■] button will light.

MEMO During the count-in, the count measure is indicated in the lower right of the display as "-2" then "-1."

NOTE If you record additional parts without erasing the previously recorded song, the song tempo and time signature will remain as it was when the song was first recorded.

12. To stop recording, press the [►/■] button.**Listening to the Recorded Performance****13. In the song select screen, press the [◀◀] button.**

You will return to the beginning of the recorded performance.

14. Press the [►/■] button.

The recorded performance will play back.

15. When you press the [►/■] button once again, playback will stop.

MEMO If you hold down one of the track buttons while you press the [●] button, the performance of only that track will be erased. If you erase the performance from all tracks, the display will indicate "New Song."

NOTE The recorded performance will disappear when you turn off the power. If you want to keep the performance you recorded, you must save it in internal memory or USB memory. Refer to "Saving the Songs You Record" (p. 70).

NOTE If you have not saved the performance you recorded, you won't be able to play back another song. You'll have to erase (p. 66) or save (p. 70) the performance before playing back another song.

Recording Your Playing Along with a Song

Here's how you can play along with an internal memory song or an external memory song, and record your performance.

For example, you can listen to the left-hand part while you record the right-hand part. The performance you play on the keyboard will be recorded in place of the sound of the part you select using the track buttons.



The sound of the track button you selected will not be heard during recording.



Performance Settings

1. Select a song.

For details on how to select a song, refer to "Listening to Songs" (p. 48).

If you want to record along with a song from external memory, connect USB memory or floppy disk drive before you continue (p. 22).



By adjusting the playback volume of the song, you can also change the volume balance between the song and the sound you're playing from the keyboard (p. 53).

2. Select the Tone to be played (p. 26).

3. Specify the recording tempo.




The performance will be recorded at the tempo of the song you selected when recording. If you record your playing along with a song, it will be recorded with the time signature of that song.

Settings for Recording


4. Press the [●] button.

The following screen will appear.



5. Press the [●] button once again.

The following screen will appear.



6. Press the track button for the part you want to record, making the button flash.

This allows you to record while listening to the selected song.
The [●] button will light, the [►/■] button indicator will flash, and the HP207 will enter recording standby mode.
If you decide not to record, press the [●] button once again.

How performance parts correspond with track buttons

Track button	Performance part
Track [Right] button	Right-hand part
Track [Left] button	Left-hand part
Track [Accomp] button	Performance data other than the right-hand part and left-hand part

Starting Recording

7. Press the [►/■] button.

After a two-measure count, recording will begin.
Even if you don't press the [►/■] button, recording will begin when you play the keyboard. In this case, a count won't be sounded.
When recording begins, the [●] button and [►/■] button will light.

 During the count, the count measure is indicated in the lower right of the display as "-2" then "-1."

Stopping Recording

8. Press the [▶/■] button.

Recording will stop.

Listening to the Recorded Performance

9. In the song select screen, press the [◀◀] button.

You will return to the beginning of the recorded performance.

10. Press the [▶/■] button.

The recorded performance will play.

11. Press the [▶/■] button once again to stop playback.

NOTE The recorded performance will disappear when you turn off the power. If you want to keep the performance you recorded, you must save it in internal memory or USB memory. Refer to "Saving the Songs You Record" (p. 70).

NOTE If you have not saved the performance you recorded, you won't be able to play back demo songs (p. 66).

Erasing Recorded Performances

You can erase recorded performances.



1. Press the [Song] button.

The screen for the recorded performance will appear.



2. Press the [+] button.

A confirmation message appears in the display.



If you decide not to delete the song, press the [▶/■] button.

3. Press the [●] button.

The recorded performance is erased.

MEMO You can also erase the recorded performance by holding down the [Song] button and pressing the [●] button.

MEMO If you hold down one of the track buttons and press the [●] button, the performance of only that track will be erased. If you erase the performances from all tracks, the display will indicate "New Song."

MEMO A performance you recorded will be deleted automatically when you turn off the power.

Saving Your Performance

Initializing the Memory

Here's how you can completely erase all songs that were saved in internal memory, USB memory (sold separately), or a floppy disk (sold separately).

NOTE Once an initialization is performed, all songs that have been saved in memory will be erased. The erased data cannot be recovered, so we recommend that you check the contents of memory before you proceed.

NOTE If you're using new USB memory (sold separately) with the HP207 for the first time, you'll need to initialize (format) the USB memory before using it. The HP207 can't use USB memory that has not been initialized.



1. If you will be initializing internal memory, connect the USB memory to the external memory connector (p. 22).
If you will be initializing a floppy disk, connect your floppy disk drive to the external memory connector, and insert the disk into the drive.

2. Press the [File] button.

The File Menu screen will appear.

3. Use the [▲] [▼] buttons to select "Format Media."



4. Press the [▶/■] button.

The Initialize Media screen will appear.



5. Use the [-][+] buttons to select whether you will initialize Internal Memory, External Memory (USB memory), or Disk (floppy disk).

6. Press the [▶/■] button.

A confirmation message will appear.



If you press the [▶/■] button, you'll return to the previous screen without initializing.

7. Press the [●] button.

Initialization will begin.

The entire contents of the selected memory will be erased.

NOTE Never turn off the power while the screen indicates "Executing..." Doing so will destroy the memory being initialized, rendering it unusable.

NOTE If the screen indicates "Error," please refer to "Error Messages" (p. 96).


NOTE Initializing the HP207's internal memory will not initialize settings other than the contents of internal memory. If you want to return settings other than the contents of internal memory to their factory-set condition, execute the Factory Reset operation (p. 86).

NOTE Don't disconnect the USB memory until USB memory initialization has been completed.

NOTE While a floppy disk is being initialized, do not eject the disk from the floppy disk drive or disconnect the cable of the disk drive.

Saving and Copying

A song you've recorded can be saved in internal memory or USB memory. Songs saved in internal memory can be copied to external memory, such as USB memory.



Saving a recorded song in internal memory

- A song you've recorded can be saved in the HP207 so it won't disappear when you turn off the power.

A song you've recorded (but not saved) will disappear when you turn off the power.

However, songs that have been saved in internal memory will not disappear when you turn off the power; the next time you turn on the power, you'll still be able to play these songs and listen to your performances.

Saving a recorded song to USB memory

- A song you've recorded can be saved to USB memory as a backup.
It's a good idea to save important performance data on USB memory.

Saving songs listened to frequently in internal memory

- Internal preset songs you're practicing can be saved in internal memory.

Saving the Songs You Record

A song you’ve recorded can be saved in internal memory or USB memory (sold separately). The songs you record will be lost if you simply turn off the HP207’s power before they’ve been saved. Since songs saved in internal memory won’t be lost when the power is turned off, it’s convenient to save a song in internal memory if you want to keep it.



- 1. If you want to save the song on USB memory, connect the USB memory to the external memory connector (p. 22).
If you want to save the song on a floppy disk, connect your floppy disk drive to the external memory connector and insert a disk into the drive.
- 2. Press the [File] button.
The file menu screen will appear.



- 3. Use the [▲] [▼] buttons to select “Save Song.”

Edit the Song Name

- 4. Press the [▶/■] button.
A screen in which you can edit the name of the song will appear.




- 5. Use the [-] [+] buttons to select the character that you want to change.
- 6. Use the tone buttons to select the character type.

Button	[Piano]	[E.piano]	[Organ]	[Strings]	[Voice]
Character	Letters	Numerals	Symbols	Insert space	Delete character


7. Use the [▲] [▼] buttons to change the character.
8. When you've finished editing the name, press the [▶/■] button.

A screen in which you can choose the save destination will appear.

Selecting the Save destination for the Song



9. Use the [-] [+] buttons to specify whether you want to save the song in internal memory (inside the HP207) or external memory (USB memory).
10. Use the [▲] [▼] buttons to highlight the save-destination number.



11. Use the [-] [+] buttons to select the save-destination number.

The song name is shown at the right of the number.

Wherever "Unused" is shown as the song name, it means that no song is saved at that number. Select a number at which no song has been saved.

If you want to erase an unwanted song and replace it with the newly saved song, select the number of the unwanted song.


Saving the Song

12. Press the [▶/■] button.

The song will be saved.

NOTE Never turn off the power while "Executing..." is shown in the display. Doing so will destroy the save-destination memory, rendering it unusable.

If in step 11 you selected a number at which a song has already been saved, the following confirmation message will appear when you press the [▶/■] button in step 12.



If you decide not to save the song, press the [▶/■] button.

If you want to erase the previously saved song and replace it with the newly saved song, press the [●] button.

Deleting a Song

Here's how you can delete a previously saved song from internal memory or USB memory.



If you want to delete all songs from internal memory, USB memory or floppy disk, refer to "Initializing the Memory" (p. 67).



1. If you're deleting a song from USB memory, connect your USB memory to the external memory connector (p. 22).
If you're deleting a song from floppy disk, connect your floppy disk drive to the external memory connector and insert the disk into the drive.

2. Press the [File] button.


The file menu screen will appear.

3. Use the [▲] [▼] buttons to select "Delete Song."




4. Press the [▶/■] button.

The Delete Song screen will appear.



Selecting the Song to Delete

5. Use the [-] [+] buttons to select whether you will be deleting a song from internal memory (the HP207's memory) or external memory (USB memory).
6. Press the [▼] button.



7. Use the [-] [+] buttons to select the song that you want to delete.

Deleting the Song

8. Press the [▶/■] button.

A confirmation message will appear.



If you decide not to delete the song, press the [▶/■] button.

9. Press the [●] button.

The selected song will be deleted.

NOTE Never turn off the power while the screen indicates "Executing..." Doing so will destroy the destination memory, rendering it unusable.

Copying a Song

Songs that have been saved in internal memory can be copied to USB memory. Alternatively, songs stored on a USB memory device can be copied to internal memory.



Preparing for the Copy

1. Connect your USB memory to the external memory connector (p. 22). Alternatively, connect your floppy disk drive to the external memory connector, and insert the disk into the drive.
2. Press the [File] button.
The file menu screen will appear.
3. Use the [▲] [▼] buttons to select "Copy Song."



4. Press the [▶/■] button.
The song copy-source selection screen will appear.



Selecting the Song to Copy

5. Use the [-] [+] buttons to select the copy-source memory.

6. Press the [▼] button.




7. Use the [-] [+] buttons to select the song that you want to copy.

If you choose "Copy all," all songs in the copy-source memory will be copied.

8. Press the [▶/■] button.

The song copy-destination selection screen will appear.



9. Use the [-] [+] buttons to select the copy-destination number.

Numbers for which a song name is shown already contain a song.

If you select a number at which a song has already been saved, and execute the copy operation, the previously saved song will be deleted.

If you don't want to delete an existing song, select an unused number.

Copying the Song

10. Press the [▶/■] button.

The selected song will be copied.


NOTE Never turn off the power while the screen indicates "Executing..."
Doing so can destroy the memory, rendering it unusable.

NOTE You cannot copy songs on audio files.

Various Settings


In “Function mode” you can make various settings for performance and recording.

Basic Operation in Function Mode



1. Hold down the [Effects] button and press the [3D] button.

A screen like the following will appear, and you'll be in Function mode.



The [Effects] button, [3D] button, and [▶/■] button will blink, and the [▲] button, [▼] button, and [Piano Designer] button will light.

2. Use the [▲] [▼] buttons to select the setting that you want to change.
3. Press the [▶/■] button to enter the setting screen.
4. Use the [-] [+] buttons to change the setting.
5. Press the [Piano Designer] button to return to the previous screen.
6. Press the [Piano Designer] button to exit Function mode.

If you want to make other settings, return to step 2 and select the setting you want to change.

The indicators on buttons will return to their original state.

NOTE The settings you change will return to their original state when you turn off the power. If you want your changes to be retained even after the power has been turned off, carry out the Memory Backup procedure (p. 86) to save the settings.

Settings you can change

Function	Page
Master Tuning	p. 77
Equalizer	p. 78
Part Mute	p. 79
Accomp Track	p. 79
Play Mode	p. 79
Metronome Sound	p. 80
Metronome Pattern	p. 80
Countdown	p. 80
Countdown Sound	p. 80
Countdown Part	p. 80
Transpose Mode	p. 81
Octave Shift	p. 81
Fix Velocity	p. 81
Damper Pedal Part	p. 81
Center Pedal Part	p. 81
Left Pedal Part	p. 81
Center Pedal Func	p. 81
Left Pedal Func	p. 81

Function	Page
Local Control	p. 82
MIDI Transmit Ch.	p. 82
Composer MIDI Out	p. 82
V-LINK	p. 83
USB Driver	p. 84
Ext. Memory Mode	p. 84
Master Gain	p. 84
3D Mode	p. 84
Track Assign	p. 85
Lyrics	p. 85
Recommended Tone	p. 85
Language	p. 85
Memory Backup	p. 86
Factory Reset	p. 86
Panel Lock	p. 87

Tuning Settings

Matching the Pitch with Other Instruments (Master Tuning)


When playing ensemble with other instruments and in other such instances, you can match the standard pitch to another instrument.

The standard pitch generally refers to the pitch of the note that's played when you finger the middle A key. For a cleaner ensemble sound while performing with one or more other instruments, ensure that each instrument's standard pitch is in tune with that of the other instruments. This tuning of all the instruments to a standard pitch is called "master tuning."


1. Hold down the [Effects] button and press the [3D] button.

The HP207 will enter Function mode.

2. Use the [▲] button to select "Master Tuning."



3. Press the [▶/■] button to enter the setting screen.



4. Use the [-] [+] buttons to set the standard pitch.

Settings
415.3 Hz–440.0 Hz–466.2 Hz

When the instrument is shipped from the factory, this is set to "40.0 (440.0 Hz)."

5. Press the [Piano Designer] button twice to exit Function mode.

Equalizer Settings

Changing the Equalizer Settings (Equalizer)

You can use the equalizer to modify the tonal character of the sound by boosting or reducing just the low-frequency or high-frequency range of the sound.

1. Hold down the [Effects] button and press the [3D] button.


2. Use the [▲] [▼] buttons to select "Equalizer."

3. Press the [▶/■] button.

The following appears in the display.




4. Press the [+] button to select "On."




5. Press the [▶/■] button.

The equalizer setting screen will appear.



6. Use the [▲] [▼] buttons to select an item.



7. Use the [-] [+] buttons to change the setting for the selected item.

Indication	Value	Description
EQ Number	1-4	Selects a set of preset equalizer settings.
High Gain	-12- +12 dB	Adjusts the level of the high-frequency range.
High Freq	1250-16k (Hz)	Frequency point in the high-frequency range. Generally, this changes the level at and over this frequency.
High Mid Gain	-12- +12 dB	Adjusts the level of the mid- to high-frequency range.
High Mid Freq	16-16k (Hz)	Frequency point in the mid- to high-frequency range to midrange. This changes the level of the specified bandwidth centered on this frequency.
High Mid Q	0.5, 1.0, 2.0, 4.0, 8.0	Changes the bandwidth of the mid- to high-frequency range. The bandwidth affected by the controls narrows as the value increases.
Low Mid Gain	-12- +12 dB	Adjusts the level of the low-frequency range to midrange.
Low Mid Freq	16-16k (Hz)	Frequency point in the low-frequency range to midrange. This changes the level of the specified bandwidth centered on this frequency.
Low Mid Q	0.5, 1.0, 2.0, 4.0, 8.0	Changes the bandwidth of the low-frequency range to midrange. The bandwidth affected by the controls narrows as the value increases.
Low Gain	-12- +12 dB	Adjusts the level of the low-frequency range.
Low Freq	100-1000 (Hz)	Frequency point in the low-frequency range. Generally, this changes the level at and below this frequency.

NOTE Sounds may become distorted as the Gain level increases.

Song playback settings

Determining the Parts that Sound (Part Mute)

For each part of the song data, you can specify whether or not it will be sounded.

1. Hold down the [Effects] button and press the [3D] button.

The HP207 will enter Function mode.

2. Use the [▲] [▼] buttons to select “Part Mute.”

3. Press the [▶/■] button.

The following appears in the display.



4. Use the [▲] [▼] buttons to select a part.

5. Use the [-] [+] buttons to select the playback status for that part.

If you press the [+] button, an “M” will appear at the left of the selected part, and that part will be muted (i.e., it will not be heard). If you press the [+] button once again, muting will be cleared.



If you press the [-] button, an “M” will appear at the left of parts other than the selected part, and only the selected part will be heard (“soloed”). Press the [-] button once again to clear this setting.



Most commercially available SMF music files consists of sixteen channels (parts).

Each channel contains a separate performance; for example, channel 1 might contain strings and channel 2 bass, with the drums on channel 10. The song data consists of these sixteen channels of performances, played back simultaneously.

Channel 1	Strings
Channel 2	Bass
:	:
Channel 10	Drums
:	:
Channel 16	Guitar

Using the [Accomp] Button to Switch the Part to be Muted (Accomp Track)

Here’s how to switch the part that will be muted when you press the [Accomp] track button and turn off its light.

Setting	Explanation
Accomp & Rhythm	Both the accompaniment and rhythm will be muted.
Accomp	Only the accompaniment will be muted. (The rhythm will not be muted.)
Rhythm	Only the rhythm will be muted. (The accompaniment will not be muted.)

NOTE The change you make to this setting will not be applied until you select a song.

Changing the Song Playback Method (Play Mode)

You can choose the way in which songs are played back on the HP207; one song at a time, or all songs successively.

Setting	Explanation
One Song	Songs will play one at a time. When the selected song has played to the end, playback will stop.
All Song	All internal preset songs, all songs in internal memory, or all songs in USB memory will continue being played consecutively.

Metronome Setting

Changing the Sound of the Metronome (Metronome Sound)

You can change the sound that's played by the metronome. The metronome will sound when you enter the setting screen.

Sound
Click, Electronic, Voice (Japanese), Voice (English), Animal, Wood Block, Triangle & Castanets, Hand Claps

Changing How the Metronome Marks the Beat (Metronome Pattern)

You can set the metronome to play at even smaller intervals. The metronome will sound when you enter the setting screen.

Setting	Explanation
Normal	Usual sound
	dotted half note
	half note
	dotted quarter note
	quarter note
	dotted eighth note
	eighth note
	sixteenth note
Double	note added to back beat of the first beat
Triplet	added notes sound the first beat as a triplet
Shuffle	notes added to create a shuffle

Sounding a Count Before the Melody Begins (Countdown)

A "count-down" is when a count is sounded at the end of the song's introduction (before you begin playing the keyboard). If you will be playing along with the song, sounding a count will help you match the timing of your playing with the song.

Setting	Explanation
On	A count is sounded
Off	A count is not sounded

Selecting the Count-down Sound (Countdown Sound)

You can select the sound that will be used to play the count-down.

Sound
Voice (English), Voice (Japanese)

Selecting the Part that Will Begin the Count-down (Countdown Part)

Specifies the part that will determine the beginning of the performance when adding a count-down. The count will sound before the selected part begins playing.

Setting	Explanation
Right & Left Track	Right-hand and left-hand parts of a song
Left Track	Left-hand part of a song
Right Track	Right-hand part of a song
Part 1-16	Part 1-16

NOTE When you select another song, this setting will return to "Right & Left Track."

Keyboard Settings

Specifying What the Key Transpose will Affect (Transpose Mode)

This setting specifies what the key transpose will affect. You can use the key transpose to change the pitch of both the song and the keyboard, the pitch of only the song, or the pitch of only the keyboard.

→ Key Transpose (p. 36), Playback Transpose (p. 55)

Setting	Explanation
Keyboard	Keyboard notes
Song	Song playback
Keyboard & Song	Keyboard notes and song playback

Changing the Pitch of the Tone in Octave Steps (Octave Shift)

You can change the pitch of the Lower Tone in Dual Play (p. 40) and Split Play (p. 43) an octave at a time.

Altering the pitch in one-octave units in this way is called "Octave Shift."

For example, you can raise the pitch of the Lower Tone to the same pitch of the Upper Tone in Split Play.

Indication
-2-0-2

The range of available pitch change spans from two octaves higher to two octaves lower.

The pitch is lowered one octave each time the [-] button is pressed, while each press of the [+] button raises the pitch by one octave.

To return to the original pitch, press the [-] and [+] buttons simultaneously.

Changing the Velocity When the Key Touch is Set to "Fixed" (Fix Velocity)

This sets the velocity the sound will have when the keyboard touch (p. 30) is set to "Fixed."

If you turn the keyboard's touch sensitivity "Fixed," all notes will sound at a fixed loudness regardless of how strongly you play the keyboard. The setting described below specifies the loudness in this case.

Indication
1-127

Pedal Settings

Changing How the Pedal Effects Are Applied (Damper/Center/Left Pedal Part)

When you press the pedal during Dual performance or Split performance, the pedal effect is normally applied to both tones, but you can also select the tone to which the effect is to be applied. This setting can be changed for each pedal.

Setting	Explanation
Right & Left	All enabled
Right	Applied only to the Tone 1 (in dual mode)/ Right-hand Tone (in split mode)
Left	Applied only to the Tone 2 (in dual mode)/ Right-hand Tone (in split mode)

Changing How the Pedals Work (Center/Left Pedal Func)

When you turn on the power, the left pedal functions as the soft pedal, and the center pedal functions as the sostenuto pedal (p. 20). You can change the function of the pedal to a variety of other operations.


Function	Description
Damper	Sets function to damper pedal.
Soft	Sets function to soft pedal.
Sostenuto	Sets function to sostenuto pedal.
Expression	Allows control of the volume.
Effects Switch	Effects can be switched on/off by pressing the pedal instead of pressing the [Effects] button. When effect type is rotary, you can control the slow/fast of spinning.
Bend Up	Pitch rises by pressing the pedal.
Bend Down	Pitch lowers by pressing the pedal.
Modulation	Vibrato is added by pressing the pedal.
Play/Stop	The pedal will have the same function as the [▶/■] button.
Layer	Pressing the pedal will layer on Tone 2, used for Dual performance. * The Layer function can be applied only when using Dual play (p. 40).
Octave	Pressing the pedal will layer on a sound one octave higher. * The Octave function cannot be applied while using Twin Piano (p. 38), Dual play (p. 40), or Split play (p. 43).

MIDI Settings


Here you can make various MIDI-related settings for the HP207.
For more about MIDI, refer to “Connecting to MIDI Devices” (p. 90).

Preventing Doubled Notes When Connected to a Sequencer (Local Control)


When you have a MIDI sequencer connected, set this parameter to Local Off.
Since the Thru function of your sequencer will normally be turned on, notes played on the keyboard or played back by the recorder will be transmitted to the sound generator by the two routes (1) and (2) shown in the illustration, causing notes to be sounded in duplicate or to be cut off unnaturally. To prevent this, the setting called “Local Off” is used to disconnect the route in (1).



Local On: The keyboard and recorder are connected to the internal sound generator.



Local Off: The keyboard and recorder are not connected to the internal sound generator. No sound will be produced by the keyboard when it is played.



Setting	Explanation
On	The Local Control is set to On. The keyboard and recorder are connected to the internal sound generator.
Off	The Local Control is set to Off. The keyboard and recorder are not connected to the internal sound generator. Playing the keyboard or playing back a song will not produce sound.

MEMO When connecting a unit in the Roland MT series, you don't need to switch off Local Control. MT units transmit Local Off messages when their power is switched on. If you first switch on the HP207, then the MT-series device, Local Control is automatically switched off on the HP207.

MIDI Transmit Channel Settings (MIDI Transmit Ch.)

this setting specifies the MIDI channel on which the HP207 will transmit.
MIDI uses sixteen “MIDI channels,” which are numbered 1 through 16.
By connecting MIDI devices and specifying the appropriate MIDI channel for each device, you can play or select sounds on those devices.
The HP207 will receive all sixteen channels (1–16).

Settings (Channel)
Off, 1–16

MEMO If you turn this “OFF,” the HP207 will not transmit MIDI data.

MEMO For details on connecting MIDI devices, refer to “Connecting to MIDI Devices” (p. 90).

Sending Recorded Performance Data to a MIDI Device (Composer MIDI Out)

When Composer MIDI Out is “On,” you can send performance data recorded with the HP207 to a connected MIDI device or computer.

Setting	Explanation
On	Performance data is transmitted.
Off	Performance data is not transmitted.

Other Settings

Using the V-LINK Function (V-LINK)

Connecting the HP207 to a V-LINK compatible image device allows you to control the images with the HP207.

NOTE To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.

V-LINK

V-LINK (**V-LINK**) is functionality promoted by Roland that allows linked performance of music and visual material. By using V-LINK-compatible video equipment, visual effects can be easily linked to, and made part of the expressive elements of a performance.

How to Use the V-LINK

1. Hold down the [Effects] button and press the [3D] button.

The HP207 will enter Function mode.

2. Use the [▲] [▼] buttons to select "V-LINK."



3. Press the [▶/■] button.

The following appears in the display.



4. Press the [-] or [+] button to switch the V-LINK function On or off.


Setting	Explanation
On	The V-LINK function is switched on.
Off	The V-LINK function is switched off.

5. Press the [Piano Designer] button twice to return to the tone select screen.

When the V-LINK function is on, the V-LINK icon appears on the screen.



You can control images using the twelve keys at the left end of the keyboard.



NOTE While V-LINK is switched on, no sound is produced when you press any of the twelve keys at the left end of the keyboard.

To disengage V-LINK, repeat steps 1–3 on the preceding page, and choose "off" in step 4.

Changing the USB Driver Settings (USB Driver)

Normally, you don't need to install a driver in order to connect the HP207 to your computer. However, if some problem occurs, or if the performance is poor, using the Roland original driver may solve the problem.

Specify the USB driver you want to use, and then install the driver.

Setting	Explanation
Generic	Choose this if you want to use the standard USB driver that was included with your computer. Normally, you should use this mode.
Original	Choose this if you want to use a USB driver downloaded from the Roland website.

If you change this setting, turn on the power once again.



For details on downloading and installing the Roland original driver, refer to the Roland website.
Roland website:
<http://www.roland.com/>



For details on connecting your computer via the USB connector, refer to "Connecting a Computer" (p. 91)



This setting is remembered even when the power is turned off.

Changing the External Memory Setting (Ext. Memory Mode)

In some cases, when USB memory is connected to the external memory connector, it may take longer for data to be loaded, or data may fail to be loaded successfully. If this occurs, you may be able to solve the problem by changing the external memory setting.

Setting
Mode 1, Mode2

If you change this setting, turn on the power once again.



This setting is remembered even when the power is turned off.

Adjusting the Volume (Master Gain)

If you are playing the HP207 through a connected external system, there may be cases in which the volume from your external system is too low even when the HP207's volume is turned to the maximum setting. In such cases, you can adjust the master gain setting as follows.

Adjusting the master gain will also affect the volume of the internal speakers and headphones.



The sound may distort if you increase the volume excessively.

Setting
-12-0-12 dB

Changing How Grand Space is Applied (3D Mode)

This specifies how 3D Sound Control (p. 31) will be applied.

Setting	Explanation
Auto	When the headphones are connected, the depth effect is optimized for headphones, and when no headphones are connected, the optimal depth for speakers is applied.
Speaker	The optimal depth for speakers is used, regardless of whether or not headphones are connected. Grand Space is also applied to the sound output from the Output connectors, making this convenient when you want to play through speakers connected to the Output connectors.
Headphones	The optimal depth for headphones is used, regardless of whether or not headphones are connected.

Changing the Parts Assigned to the Track Buttons During SMF Playback (Track Assign)

Ordinarily, when playing back SMF music files for Roland Piano Digital instruments (p. 106), the left-hand part is assigned to the Track [Left] button, and the right-hand part is assigned to the Track [Right] button. However, right-hand and left-hand part assignments in certain SMF music files may differ.

If these are set to "Auto," and as a result you are unable to use the track buttons to control the left- and right-hand parts (p. 52) properly, change the setting to "2/1 Part" or "3/4 Part."

NOTE This setting can be used for SMF format songs other than the internal preset songs. It will not affect internal preset songs.

Setting	Explanation
Auto	The part assigned to each track will be determined automatically, depending on the song file.
2/1 Part	Part 1 will be assigned to the right-hand track, part 2 to the left-hand track, and part 3 to the user track.
3/4 Part	Part 4 will be assigned to the right-hand track, part 3 to the left-hand track, and part 1 to the user track.

NOTE After changing this setting, try selecting the song once again.

Switching On/Off the Display of Lyrics (Lyrics)

This lets you specify whether lyrics will be displayed in the screen when you play back song data that contains lyrics.

Setting	Explanation
On	Lyrics will be displayed.
Off	Lyrics will not be displayed.

This is set to "On" at the factory.

Switching VIMA TUNES Recommended Tones (Recommended Tone)

You can connect a commercially available USB CD drive to the HP207, and play back separately sold CD-ROMs created for the VIMA (VIMA TUNES).

Songs on VIMA CD-ROM (VIMA TUNES) are programmed with "recommended tones" suitable for each song.

When you select a song from a VIMA CD-ROM (VIMA TUNES), recommended tones will be assigned to the HP207's [Strings], [Voice], and [Others] tone buttons, and these three tone buttons will blink.

When you press a flashing Tone button, the recommended tone is then selected, enabling you to perform the selected song using a tone matched to that song as it plays back.

You can set the HP207 so that the recommended tones are automatically assigned or not assigned.

Setting	Explanation
On	When you select a song from a VIMA CD-ROM (VIMA TUNES), recommended tones will automatically be assigned to the HP207's [Strings], [Voice], and [Others] tone buttons.
Off	The recommended tones are not used, and only the HP207's internal tones can be selected.

This is set to "On" at the factory.

Changing the Language Displayed in the Screen (Language)

You can change the language that is displayed in the screen.

Settings
English, Japanese

Remembering the Settings (Memory Backup)

Normally, the settings of the various variations will revert to their default values when the power is turned off. However, you can specify that the various settings will be remembered even when the power is turned off.

This function is called "Memory Backup."

1. Hold down the [Effects] button and press the [3D] button.


The HP207 will enter Function mode.

2. Use the [▲] [▼] buttons to select "Memory Backup."



3. Press the [▶/■] button.


The following appears in the display.



If you decide to cancel without executing, press the [Piano Designer] button.

4. If you're sure you want to execute Memory Backup, press [▶/■].

A confirmation message appears in the screen.



5. Press the [●] button.

If you decide to cancel without executing, press the [▶/■] button.

When the memory backup operation is completed, the function mode menu screen will appear.

NOTE For details on the items that are memorized, refer to "Parameters Stored in Memory Backup" (p. 105).

Restoring the Settings to the Factory Condition (Factory Reset)

The settings you've changed in Function mode can be restored to their factory-set condition. This operation is called "Factory Reset."

Execute this operation if you want the settings you've stored using Memory Backup to be returned to their original state.

NOTE When you execute "Factory Reset," all settings you've stored up to that point will be cleared, and reset to their factory-set condition.

MEMO Executing this operation will not erase the songs from internal memory or USB memory. If you want to erase all songs from the HP207's internal memory and all songs from USB memory, refer to "Initializing the Memory" (p. 67).

1. Hold down the [Effects] button and press the [3D] button.


The HP207 will enter Function mode.

2. Use the [▲] [▼] buttons to select "Factory Reset."



3. Press the [▶/■] button.

The following appears in the display.



If you decide to cancel without executing, press the [Piano Designer] button.

4. If you're sure you want to execute Factory Reset, press [▶/■].


A confirmation message appears in the screen.



5. Press the [●] button.

If you decide to cancel without executing, press the [▶/■] button.

When the Factory Reset is complete and the following appears in the screen.



6. Turn the [Volume] knob all the way toward the left to minimize the volume.

7. Switch the power off, then back on.

Disabling the Buttons (Panel Lock)

If you activate the Panel Lock function, all buttons will be locked and non-functional. You can use this to prevent a child from accidentally changing the settings by inadvertently pressing buttons.

1. Press the [Effect] button and [File] button simultaneously.

Panel Lock will be activated.

A key symbol will appear in the upper right of the screen, and all buttons will be disabled.



Canceling the Panel Lock function

Once again, press the [Effect] button and [File] button simultaneously.



Panel Lock will be cancelled when you turn off the power.

Connecting to Other Devices

Connecting to Audio Equipment


You can connect audio devices to play the sound of the HP207 through the speakers of your audio system, or to record your performance on a tape recorder or other recording device.

Use phone plug audio cables (sold separately) to make connections.

* When connection cables with resistors are used, the volume level of equipment connected to the input jacks may be low. If this happens, use connection cables that do not contain resistors.

* To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.

Connecting Speakers to the HP207 and Outputting Sounds




1. Turn the volume all the way down on the HP207 and on the device you're about to connect.
2. Turn off the power to the HP207 and connected speakers.
3. Use audio cables (sold separately) to make the connection.
4. Switch on the HP207.
5. Switch on the connected speakers.
6. Adjust the volume level on the HP207 and the connected speakers.

When you play the HP207's keyboard, the sound is played from the connected speakers.

Turning Off the Power

1. Turn the volume all the way down on the HP207 and on the speakers you're about to connect.
2. Turn off the connected speakers.
3. Turn off the HP207.

Playing Sounds of an Audio Device through the HP207



- 1.** Turn the volume all the way down on the HP207 and on the audio device you're about to connect.
- 2.** Turn off the power to the HP207 and connected audio device.
- 3.** Use audio cables (sold separately) to make the connection.
- 4.** Switch on the connected audio device.
- 5.** Switch on the HP207.
- 6.** Adjust the volume level on the HP207 and the connected audio device.

The sounds from the connected audio device are played by the HP207.



Adjust the volume by using the controls of your audio device.

Turning Off the Power

- 1.** Turn the volume all the way down on the HP207 and on the audio device you're about to connect.
- 2.** Turn off the HP207.
- 3.** Turn off the connected audio device.

Connecting to MIDI Devices


By connecting an external MIDI device and exchanging performance data, you can control one device from the other. For instance, you can output sound from the other instrument or switch Tones on the other instrument.

What's MIDI?

MIDI, short for "Musical Instrument Digital Interface," was developed as a universal standard for the exchange of performance data between electronic instruments and computers.


The HP207 is equipped with MIDI connectors to let it exchange performance data with external devices. These connectors can be used to connect the HP207 to an external device for even greater versatility.

Connecting a Computer to the HP207



When the HP207 is connected to a MIDI sequencer, set it to "Local Off." Refer to "Preventing Doubled Notes When Connected to a Sequencer (Local Control)" (p. 82).

Producing Sounds from a MIDI Sound Module by Playing the HP207



Making the Connection

1. Turn the volume all the way down on the HP207 and on the MIDI device you're about to connect.
2. Switch off the power to the HP207 and the MIDI device you're about to connect.
3. Use a MIDI cables (sold separately) to connect the MIDI connectors to each other.
4. Switch on the power to the HP207 and the connected device.
5. Adjust the volume level on the HP207 and the connected device.
6. You should also set the MIDI transmit channel as needed.




For details on the MIDI transmit channel, refer to "MIDI Transmit Channel Settings (MIDI Transmit Ch.)" (p. 82).

Connecting a Computer

The following become possible once you connect a USB cable (available separately) between the USB (MIDI) connector on the HP207's rear panel and the USB connector of your computer.

- You can use the HP207 to play sounds from SMF music files played back with MIDI software.
- By exchanging MIDI data with sequencer software, you can save songs recorded with the HP207 to your computer, and enjoy a variety of musical control and editing features.

Connect the HP207 to your computer as shown below.



* Refer to the Roland website for system requirements.
Roland website: <http://www.roland.com/>

If connection to your computer is unsuccessful...

Normally, you don't need to install a driver in order to connect the HP207 to your computer. However, if some problem occurs, or if the performance is poor, using the Roland original driver may solve the problem.

For details on downloading and installing the Roland original driver, refer to the Roland website.

Roland website: <http://www.roland.com/>

Specify the USB driver you want to use, and then install the driver. For details, refer to "Changing the USB Driver Settings (USB Driver)" (p. 84).

Caution

- To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.
- Only MIDI data can be transmitted using USB.
- USB cables are not included. Consult your Roland dealer if you need to purchase.
- Turn on the power to the HP207 before starting up MIDI applications on the computer. Do not turn the HP207 on or off while any MIDI application is running.

Troubleshooting

If you think there's a problem, read this first.

Symptom	Cause/Action	Page
Power does not turn on	Is the power cord connected correctly?	p. 16
Nothing appears in the screen	Since the HP207 uses a liquid crystal screen, it may happen that no text or graphics appear in the screen if the temperature is below zero degrees Celsius (32 degrees Fahrenheit).	—
Pedal does not work, or is "stuck"	Is the pedal connected correctly? Plug the cable firmly into the pedal connector.	p. 16
	If you disconnect the pedal cable from the HP207 while the power is on, the pedal effect may remain "stuck" in the On condition. You must power-off the HP207 before connecting or disconnecting the pedal cable.	—
	If you've switched the function of the soft pedal or sostenuto pedal, these pedals will not operate as the soft pedal or sostenuto pedal.	p. 81
Unable to read from/write to USB memory	Are you using (optional) Roland USB memory? Reliable performance cannot be guaranteed if you use non-Roland USB memory products.	—
	If you are unable to read or write USB memory successfully, change the External Memory setting.	p. 84
"Buzz" is heard from external devices	Are the external devices connected to more than one AC power outlet? If you connect external devices, be sure to connect them to the same AC outlet.	—
Device connected to the Input jacks have insufficient volume	Could you be using a connection cable that contains a resistor? Use a connection cable that does not contain a resistor.	—
No sound		
No sound	Is the speaker cable connected correctly?	p. 16
	Could the HP207's volume or the volume of the connected equipment be turned down?	p. 19
	Could headphones be connected? Could there be a plug inserted in a headphone jack? The speakers will not produce sound if headphones or plug are connected to the headphone jacks.	p. 21
	Has Local Control been set to "Off"? When Local Control is set to Off, no sound is produced by playing the keyboard. Set Local Control to On.	p. 82
No sound when you play back a song	Has Local Control been set to "Off"? When Local Control is set to Off, no sound is produced by playing the keyboard. Set Local Control to On.	p. 82
	Could the song volume be set to "0"?	p. 53
No sound from the leftmost notes of the keyboard	Is V-LINK switched on? When V-LINK is on, the lowest twelve notes of the keyboard are used to control the image, and will not produce sound.	p. 83

Symptom	Cause/Action	Page
No sound (when a MIDI device is connected)	Are all devices powered on?	—
	Are the MIDI cables connected correctly?	p. 90
	Do the MIDI channels of the HP207 and the connected device match?	p. 82
Not all the notes you play are sounded	The maximum simultaneous polyphony is 128 notes. If you are playing along with a song and making heavy use of the damper pedal, the number of notes the HP207 is attempting to produce may exceed the maximum polyphony, meaning that some of the notes will drop out.	—
Notes don't sound right		
Sound is not loud enough Only the high sounds are heard	Is the speaker cable connected correctly?	p. 16
Pitch of the keyboard or song is incorrect	Could you have made Key Transpose settings?	p. 36
	Is the Master Tune setting appropriate?	p. 77
	Is the setting for the Temperament correct?	p. 29
	Is the settings for the Stretch Tuning correct?	p. 28
Sounds are heard twice (doubled) when the keyboard is played	Is the HP207 in Dual performance?	p. 40
	When the HP207 is connected to an external sequencer, set the Local Control to off. Alternatively, the sequencer could be set so its Soft Thru feature is Off.	p. 82
The wrong instrument is selected when you press the [Strings], [Voice], or [Others] button	INSTRUMENT buttons [Strings] [Voice] [Others] also operate as buttons that select "Recommended Tones." With the factory settings, connecting a commercially-available CD-ROM drive to the external memory connector and selecting a song from a CD-ROM produced for the VIMA (VIMA TUNES) will automatically cause sounds appropriate for that song to be assigned to the [Strings], [Voice], and [Others] Tone buttons, so that you can select "recommended" sounds by pressing one of these buttons. You can also make settings so that "recommended" sounds are not automatically assigned.	p. 85
Effect does not apply	When you are using Dual performance or Split performance, and different effects are specified for the two selected tones, the effect will not be applied to Tone 2 (when using Dual performance) or the left-hand tone (when using Split performance).	—
Reverberation remains even if You defeat the Reverb effect	The HP207's piano sound faithfully simulates the depth and resonance of an acoustic piano, and this may give the impression of reverberation even if you've defeated the Reverb effect.	—
The sound of the higher notes suddenly changes from a certain key	On an acoustic piano, the approximately one and a half octaves of notes at the top of the keyboard will continue sounding regardless of the damper pedal. These notes also have a somewhat different tonal character. HP207 faithfully simulate this characteristic of acoustic pianos. On the HP207, the range that is unaffected by the damper pedal will change according to the key transpose setting.	—

Troubleshooting

Symptom	Cause/Action	Page
High-pitched ringing is heard	Is the speaker cable connected correctly?	p. 16
	If you hear this in headphones: Piano sounds that have a brilliant and crisp character contain substantial high-frequency components that may sound as though a metallic ringing has been added. This is because the character of an actual piano is being faithfully reproduced, and is not a malfunction. This ringing is more obtrusive if the reverb effect is applied heavily, so you may be able to minimize it by decreasing the reverb. If you don't hear this in headphones: It is likely that there is some other reason (such as resonances within the unit). Please contact your dealer or a nearby Roland service center.	—
Low notes sound wrong, or are buzzy	If you don't hear this in headphones: Performing at high volumes may cause the speakers or objects near the HP207 to resonate. Fluorescent lights or glass doors may also resonate sympathetically. In particular, this is more likely to occur for lower notes and higher volumes. You can take the following measures to minimize resonances. • Locate the speakers 10–15 cm away from walls or other surfaces. • Keep the volume down. • Move away from the objects that are resonating. If you hear this in headphones: It is likely that there is some other reason. Please contact your dealer or a nearby Roland service center.	—
	If you set the volume to the maximum setting, the sound may be distorted depending on how you perform. If this occurs, turn down the volume. Alternatively, lower the master gain.	p. 19 p. 84
Song does not play correctly		
Song won't play	Could the screen be indicating "OK to delete Song?" You can't play back an internal song if internal memory contains performance data you recorded. Erase the performance data you recorded before you play back the song.	p. 24 p. 66
Only the sound of a particular instrument in a song does not play	Could a track be muted? If the button indicator is out, the music on that track is not heard. Press the track button so the indicator is illuminated.	p. 52
	Could the Part Mute setting be active? Muted parts will not be heard.	p. 79
Sound is heard from a muted track	Could the track mute volume be set to other than "0"? If you set this to "0," the sound of a muted track will be completely inaudible.	p. 53
Song volume is low	Could the song volume be lowered?	p. 53
Song tempo becomes unstable	When playing a song from USB memory, the tempo may become unstable if there is an excessive amount of performance data.	—

Symptom	Cause/Action	Page
Song name in USB memory is not shown	The song name will not be shown if the song information in the file is empty or consists only of spaces.	—
	Is the filename extension "MID"? Files with other filename extensions cannot be handled as song data.	—
Can't record / play back		
Can't record	Has one of the track buttons for recording been selected?	p. 60 p. 64
The recorded performance disappeared	Your recorded performance will disappear if you switch off the HP207's power or select a song. There is no way to recover the lost performance. Before you turn off the power, save your recorded performance in internal Memory.	p. 70

Error Messages

Indication	Meaning
Error: 1	You can only read the music file. It can not be saved.
Error: 2	An error occurred during writing. The external media's protect tab may be in the "Protect" (writing prohibited) position, or the external media may not yet be initialized.
Error: 10	No external media is inserted. Insert the external media and try again.
Error: 11	There is not sufficient free memory in the save destination. Either insert other external media or delete unneeded files and try again.
Error: 14	An error occurred during writing. The external media may be corrupted. Insert other external media and try again. Alternatively, you can initialize the external media.
Error: 15	The file is unreadable. The data format is not compatible with the HP207.
Error: 16	Data was not called up in time for playback of the song. After waiting several seconds, you may be able to play back the song by pressing the [►/■] button again.
Error: 18	This audio format is not supported. Please use 44.1 kHz 16-bit linear WAV format audio files.
Error: 30	The internal memory capacity of the HP207 is full.
Error: 40	The HP207 cannot deal with the excessive MIDI data sent from the external MIDI device. Reduce the amount of MIDI data sent to the HP207.
Error: 41	A MIDI cable has been disconnected. Connect it properly and securely.
Error: 43	A MIDI transmission error has occurred. Check the MIDI cable and connected MIDI device.
Error: 51	There may be a problem with the system. Repeat the procedure from the beginning. If it is not solved after you have tried several times, contact the Roland service center.
Error: 65	The External Memory port was subjected to excessive current. Make sure that there is no problem with the external media, then turn the power off, then on again.

* External Media: USB memory, CD-ROM, etc.

Tone List

Piano

001	Grand Piano1
002	Piano + Str.
003	Harpsichord
004	Grand Piano2
005	Piano + Pad
006	Grand Piano3
007	MagicalPiano
008	Rock Piano
009	Piano+Choir
010	Honky-tonk
011	Coupled Hps.

E.Piano

001	Pop E.Piano
002	Vintage EP
003	FM E.Piano
004	Vibraphone
005	EP Belle
006	Celesta
007	'60s E.Piano
008	Clav.
009	Mallet Isle
010	Morning Lite
011	Marimba
012	Stage Phaser
013	Ballad Bells
014	'70s E.Piano
015	E.Grand

Organ

001	ChurchOrgan1
002	ChurchOrgan2
003	Combo Jz.Org
004	Ballad Organ
005	Accordion
006	Nason flt 8'
007	Gospel Spin
008	Full Stops
009	Mellow Bars
010	Light Organ
011	Lower Organ
012	'60s Organ

Strings

001	Rich Strings
002	OrchestraStr
003	Orchestra
004	ChamberWinds
005	Harp
006	Violin
007	Velo Strings
008	Flute
009	Cello
010	OrchestraBrs
011	PizzicatoStr
012	DecayStrings *

Voice

001	Aerial Choir
002	Jazz Scat
003	Harpvox
004	Glass Pad
005	Angels Choir
006	Beauty Vox
007	Soft Pad
008	Female Aahs
009	Male Aahs
010	Thum Voice
011	Lunar Strngs
012	Decay Choir *
013	Dcy ChoirPad *

* Tones indicated by "*" are suitable for playing layered with a piano tone.

Others

001	Nylon-str.Gt
002	Steel-str.Gt
003	Jazz Guitar
004	AcousticBass
005	A.Bass+Cymb
006	FingeredBass
007	BrassSection
008	Alto Sax
009	Tenor Sax
GM2	
010	STANDARD Set
011	ROOM Set
012	POWER Set
013	ELEC.Set
014	ANALOG Set
015	JAZZ Set
016	BRUSH Set
017	ORCH.Set
018	SFX Set
* 010-018 are drum sets. Refer to p. 101-p. 103 for details on the sounds in the drum sets.	
019	Piano 1
020	Piano 1w
021	Piano 1d
022	Piano 2
023	Piano 2w
024	Piano 3
025	Piano 3w
026	Honky-tonk
027	Honky-tonk w
028	E.Piano 1
029	Detuned EP 1
030	Vintage EP
031	'60s E.Piano
032	E.Piano 2

033	Detuned EP 2
034	St.FM EP
035	EP Legend
036	EP Phase
037	Harpsichord
038	Coupled Hps.
039	Harpsi.w
040	Harpsi.o
041	Clav.
042	Pulse Clav.
043	Celesta
044	Glockenspiel
045	Music Box
046	Vibraphone
047	Vibraphone w
048	Marimba
049	Marimba w
050	Xylophone
051	TubularBells
052	Church Bell
053	Carillon
054	Santur
055	Organ 1
056	TremoloOrgan
057	'60s Organ
058	Organ 2
059	Perc.Organ 1
060	Chorus Organ
061	Perc.Organ 2
062	Rock Organ
063	Church Org.1
064	Church Org.2
065	Church Org.3
066	Reed Organ
067	Puff Organ
068	Accordion 1
069	Accordion 2

070	Harmonica
071	Bandoneon
072	Nylon-str.Gt
073	Ukulele
074	Nylon Gt o
075	Nylon Gt 2
076	Steel-str.Gt
077	12-str.Gt
078	Mandolin
079	Steel+Body
080	Jazz Guitar
081	Hawaiian Gt
082	Clean Guitar
083	Chorus Gt 1
084	Mid Tone Gt
085	Muted Guitar
086	Funk Guitar1
087	Funk Guitar2
088	Chorus Gt 2
089	Overdrive Gt
090	Guitar Pinch
091	DistortionGt
092	Gt Feedback1
093	Dist.Rtm Gt
094	Gt Harmonics
095	Gt Feedback2
096	AcousticBass
097	FingeredBass
098	Finger Slap
099	Picked Bass
100	FretlessBass
101	Slap Bass 1
102	Slap Bass 2
103	Synth Bass 1
104	WarmSyn.Bass
105	Synth Bass 3
106	Clav.Bass

107	Hammer	144	Tuba	181	SequencedSaw
108	Synth Bass 2	145	MuteTrumpet1	182	Syn.Calliope
109	Synth Bass 4	146	MuteTrumpet2	183	Chiffer Lead
110	RubberSyn.Bs	147	French Horn1	184	Charang
111	Attack Pulse	148	French Horn2	185	Wire Lead
112	Violin	149	Brass 1	186	Solo Vox
113	Slow Violin	150	Brass 2	187	5th Saw Lead
114	Viola	151	Synth Brass1	188	Bass+Lead
115	Cello	152	Synth Brass3	189	Delayed Lead
116	Contrabass	153	AnalogBrass1	190	Fantasia
117	Tremolo Str.	154	Jump Brass	191	Warm Pad
118	PizzicatoStr	155	Synth Brass2	192	Sine Pad
119	Harp	156	Synth Brass4	193	Polysynth
120	Yang Qin	157	AnalogBrass2	194	Space Voice
121	Timpani	158	Soprano Sax	195	Itopia
122	Strings	159	Alto Sax	196	Bowed Glass
123	Orchestra	160	Tenor Sax	197	Metallic Pad
124	'60s Strings	161	Baritone Sax	198	Halo Pad
125	Slow Strings	162	Oboe	199	Sweep Pad
126	Syn.Strings1	163	English Horn	200	Ice Rain
127	Syn.Strings3	164	Bassoon	201	Soundtrack
128	Syn.Strings2	165	Clarinet	202	Crystal
129	Choir 1	166	Piccolo	203	Synth Mallet
130	Choir 2	167	Flute	204	Atmosphere
131	Voice	168	Recorder	205	Brightness
132	Humming	169	Pan Flute	206	Goblins
133	Synth Voice	170	Bottle Blow	207	Echo Drops
134	Analog Voice	171	Shakuhachi	208	Echo Bell
135	OrchestraHit	172	Whistle	209	Echo Pan
136	Bass Hit	173	Ocarina	210	Star Theme
137	6th Hit	174	Square Lead1	211	Sitar 1
138	Euro Hit	175	Square Lead2	212	Sitar 2
139	Trumpet	176	Sine Lead	213	Banjo
140	Dark Trumpet	177	Saw Lead 1	214	Shamisen
141	Trombone 1	178	Saw Lead 2	215	Koto
142	Trombone 2	179	Doctor Solo	216	Taisho Koto
143	Bright Tb	180	Natural Lead	217	Kalimba

Tone List

218	Bagpipe
219	Fiddle
220	Shanai
221	Tinkle Bell
222	Agogo
223	Steel Drums
224	Woodblock
225	Castanets
226	Taiko
227	Concert BD
228	Melodic Tom1
229	Melodic Tom2
230	Synth Drum
231	TR-808 Tom
232	Elec.Perc.
233	Reverse Cym.
234	Gt FretNoise
235	Gt Cut Noise
236	BsStringSlap
237	Breath Noise
238	Fl.Key Click
239	Seashore
240	Rain
241	Thunder
242	Wind
243	Stream
244	Bubble
245	Bird 1
246	Dog
247	Horse Gallop
248	Bird 2
249	Telephone 1
250	Telephone 2
251	DoorCreaking
252	Door
253	Scratch
254	Wind Chimes

255	Helicopter
256	Car Engine
257	Car Stop
258	Car Pass
259	Car Crash
260	Siren
261	Train
262	Jetplane
263	Starship
264	Burst Noise
265	Applause
266	Laughing
267	Screaming
268	Punch
269	Heart Beat
270	Footsteps
271	Gun Shot
272	Machine Gun
273	Laser Gun
274	Explosion

* In the tone group "Others" when you hold down the [-] or [+] button to switchtone in succession, the tones will stop changing at number 010 and number 019.
To select the next sound, release the [-] or [+] button, then press it again.

	Standard Set	Room Set	Power Set	Electronic Set
27	High-Q	High-Q	High-Q	High-Q
28	Slap	Slap	Slap	Slap
29	Scratch Push [EXC7]	Scratch Push [EXC7]	Scratch Push [EXC7]	Scratch Push [EXC7]
30	Scratch Pull [EXC7]	Scratch Pull [EXC7]	Scratch Pull [EXC7]	Scratch Pull [EXC7]
31	Sticks	Sticks	Sticks	Sticks
32	Square Click	Square Click	Square Click	Square Click
33	Metronome Click	Metronome Click	Metronome Click	Metronome Click
34	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell
35	Kick Drum 2	Room Kick 2	Room Kick 1	Power Kick
C2 36	Kick Drum 1	Room Kick 1	Power Kick	Electric Kick
37	Side Stick	Side Stick	Side Stick	Side Stick
38	Snare Drum	Room Snare	Power Snare	Electric Snare 1
39	Hand Clap	Hand Clap	Hand Clap	Hand Clap
40	Electric Snare 3	Electric Snare 4	Electric Snare 5	Electric Snare 2
41	Low Tom 2	Room Low Tom 2	Power Low Tom 2	Electric Low Tom 2
42	Closed Hi-Hat 1 [EXC1]	Closed Hi-Hat 2 [EXC1]	Closed Hi-Hat 2 [EXC1]	Closed Hi-Hat 2 [EXC1]
43	Low Tom 1	Room Low Tom 1	Power Low Tom 1	Electric Low Tom 1
44	Pedal Hi-Hat 1 [EXC1]	Pedal Hi-Hat 2 [EXC1]	Pedal Hi-Hat 2 [EXC1]	Pedal Hi-Hat 2 [EXC1]
45	Mid Tom 2	Room Mid Tom 2	Power Mid Tom 2	Electric Mid Tom 2
46	Open Hi-Hat 1 [EXC1]	Open Hi-Hat 2 [EXC1]	Open Hi-Hat 2 [EXC1]	Open Hi-Hat 2 [EXC1]
47	Mid Tom 1	Room Mid Tom 1	Power Mid Tom 1	Electric Mid Tom 1
C3 48	High Tom 2	Room High Tom 2	Power High Tom 2	Electric High Tom 2
49	Crash Cymbal 1	Crash Cymbal 3	Crash Cymbal 3	Crash Cymbal 3
50	High Tom 1	Room High Tom 1	Power High Tom 1	Electric High Tom 1
51	Ride Cymbal 1	Ride Cymbal 3	Ride Cymbal 3	Ride Cymbal 3
52	Chinese Cymbal 1	Chinese Cymbal 2	Chinese Cymbal 2	Reverse Cymbal
53	Ride Bell 1	Ride Bell 2	Ride Bell 2	Ride Bell 2
54	Tambourine	Tambourine	Tambourine	Tambourine
55	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal
56	Cowbell	Cowbell	Cowbell	Cowbell
57	Crash Cymbal 2	Crash Cymbal 4	Crash Cymbal 4	Crash Cymbal 4
58	Vibraslap	Vibraslap	Vibraslap	Vibraslap
59	Ride Cymbal 2	Ride Cymbal 4	Ride Cymbal 4	Ride Cymbal 4
C4 60	High Bongo 1	High Bongo 2	High Bongo 2	High Bongo 2
61	Low Bongo 1	Low Bongo 2	Low Bongo 2	Low Bongo 2
62	Mute High Conga 1	Mute High Conga 2	Mute High Conga 2	Mute High Conga 2
63	Open High Conga	Open High Conga	Open High Conga	Open High Conga
64	Low Conga	Low Conga	Low Conga	Low Conga
65	High Timbale	High Timbale	High Timbale	High Timbale
66	Low Timbale	Low Timbale	Low Timbale	Low Timbale
67	High Agogo	High Agogo	High Agogo	High Agogo
68	Low Agogo	Low Agogo	Low Agogo	Low Agogo
69	Cabasa	Cabasa	Cabasa	Cabasa
70	Maracas	Maracas	Maracas	Maracas
71	Short High Whistle [EXC2]	Short High Whistle [EXC2]	Short High Whistle [EXC2]	Short High Whistle [EXC2]
C5 72	Long Low Whistle [EXC2]	Long Low Whistle [EXC2]	Long Low Whistle [EXC2]	Long Low Whistle [EXC2]
73	Short Guiro [EXC3]	Short Guiro [EXC3]	Short Guiro [EXC3]	Short Guiro [EXC3]
74	Long Guiro [EXC3]	Long Guiro [EXC3]	Long Guiro [EXC3]	Long Guiro [EXC3]
75	Claves	Claves	Claves	Claves
76	High Woodblock	High Woodblock	High Woodblock	High Woodblock
77	Low Woodblock	Low Woodblock	Low Woodblock	Low Woodblock
78	Mute Cuica [EXC4]	Mute Cuica [EXC4]	Mute Cuica [EXC4]	Mute Cuica [EXC4]
79	Open Cuica [EXC4]	Open Cuica [EXC4]	Open Cuica [EXC4]	Open Cuica [EXC4]
80	Mute Triangle [EXC5]	Mute Triangle [EXC5]	Mute Triangle [EXC5]	Mute Triangle [EXC5]
81	Open Triangle [EXC5]	Open Triangle [EXC5]	Open Triangle [EXC5]	Open Triangle [EXC5]
82	Shaker	Shaker	Shaker	Shaker
83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
C6 84	Bar Chimes	Bar Chimes	Bar Chimes	Bar Chimes
85	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo [EXC6]	Mute Surdo [EXC6]	Mute Surdo [EXC6]	Mute Surdo [EXC6]
87	Open Surdo [EXC6]	Open Surdo [EXC6]	Open Surdo [EXC6]	Open Surdo [EXC6]
88	-----	-----	-----	-----

* ----- : No sound.

* [EXC]: will not sound simultaneously with other percussion instruments of the same number.

Tone List

	Analog Set	Jazz Set	Brush Set	Orchestra Set
27	High-Q	High-Q	High-Q	Closed Hi-Hat 2 [EXC1]
28	Slap	Slap	Slap	Pedal Hi-Hat 2 [EXC1]
29	Scratch Push [EXC7]	Scratch Push [EXC7]	Scratch Push [EXC7]	Open Hi-Hat 2 [EXC1]
30	Scratch Pull [EXC7]	Scratch Pull [EXC7]	Scratch Pull [EXC7]	Ride Cymbal 3
31	Sticks	Sticks	Sticks	Sticks
32	Square Click	Square Click	Square Click	Square Click
33	Metronome Click	Metronome Click	Metronome Click	Metronome Click
34	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell
35	TR-808 Kick 2	Room Kick 2	Room Kick 2	Concert Bass Drum 2
C2 36	TR-808 Kick 1	Jazz Kick	Jazz Kick	Concert Bass Drum 1
37	TR-808 Rim shot	Side Stick	Side Stick	Side Stick
38	TR-808 Snare	Jazz Snare	Brush Tap	Concert Snare Drum
39	Hand Clap	Hand Clap	Brush Slap1	Castanets
40	Electric Snare 6	Electric Snare 7	Brush Swirl	Concert Snare Drum
41	TR-808 Low Tom 2	Jazz Low Tom	Brush Low Tom 2	Timpani F
42	TR-808 Closed Hi-Hat 1 [EXC1]	Closed Hi-Hat 2 [EXC1]	Brush Closed Hi-Hat [EXC1]	Timpani F#
43	TR-808 Low Tom 1	Low Tom 1	Brush Low Tom 1	Timpani G
44	TR-808 Closed Hi-Hat 2 [EXC1]	Pedal Hi-Hat 2 [EXC1]	Brush Pedal Hi-Hat [EXC1]	Timpani G#
45	TR-808 Mid Tom 2	Mid Tom 2	Brush Mid Tom 2	Timpani A
46	TR-808 Open Hi-Hat [EXC1]	Open Hi-Hat 2 [EXC1]	Brush Open Hi-Hat [EXC1]	Timpani A#
47	TR-808 Mid Tom 1	Jazz Mid Tom	Brush Mid Tom 1	Timpani B
C3 48	TR-808 High Tom 2	Jazz High Tom 2	Brush High Tom 2	Timpani C
49	TR-808 Crash Cymbal	Crash Cymbal 3	Jazz Crash Cymbal	Timpani C#
50	TR-808 High Tom 1	Jazz High Tom 1	Brush High Tom 1	Timpani D
51	Ride Cymbal 3	Ride Cymbal 3	Jazz Ride Cymbal 1	Timpani D#
52	Chinese Cymbal 2	Chinese Cymbal 2	Chinese Cymbal 2	Timpani E
53	Ride Bell 2	Ride Bell 2	Jazz Ride Cymbal 2	Timpani F
54	Tambourine	Tambourine	Tambourine	Tambourine
55	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal
56	TR-808 Cowbell	Cowbell	Cowbell	Cowbell
57	Crash Cymbal 4	Crash Cymbal 4	Crash Cymbal 4	Concert Cymbal 2
58	Vibraslap	Vibraslap	Vibraslap	Vibraslap
59	Ride Cymbal4	Ride Cymbal4	Ride Cymbal4	Concert Cymbal 1
C4 60	High Bongo 2	High Bongo 2	High Bongo 2	High Bongo 2
61	Low Bongo 2	Low Bongo 2	Low Bongo 2	Low Bongo 2
62	TR-808 High Conga	Mute High Conga 2	Mute High Conga 2	Mute High Conga 2
63	TR-808 Mid Conga	Open High Conga	Open High Conga	Open High Conga
64	TR-808 Low Conga	Low Conga	Low Conga	Low Conga
65	High Timbale	High Timbale	High Timbale	High Timbale
66	Low Timbale	Low Timbale	Low Timbale	Low Timbale
67	High Agogo	High Agogo	High Agogo	High Agogo
68	Low Agogo	Low Agogo	Low Agogo	Low Agogo
69	Cabasa	Cabasa	Cabasa	Cabasa
70	TR-808 Maracas	Maracas	Maracas	Maracas
71	Short High Whistle [EXC2]	Short High Whistle [EXC2]	Short High Whistle [EXC2]	Short High Whistle [EXC2]
C5 72	Long Low Whistle [EXC2]	Long Low Whistle [EXC2]	Long Low Whistle [EXC2]	Long Low Whistle [EXC2]
73	Short Guiro [EXC3]	Short Guiro [EXC3]	Short Guiro [EXC3]	Short Guiro [EXC3]
74	Long Guiro [EXC3]	Long Guiro [EXC3]	Long Guiro [EXC3]	Long Guiro [EXC3]
75	Claves	Claves	Claves	Claves
76	High Woodblock	High Woodblock	High Woodblock	High Woodblock
77	Low Woodblock	Low Woodblock	Low Woodblock	Low Woodblock
78	Mute Cuica [EXC4]	Mute Cuica [EXC4]	Mute Cuica [EXC4]	Mute Cuica [EXC4]
79	Open Cuica [EXC4]	Open Cuica [EXC4]	Open Cuica [EXC4]	Open Cuica [EXC4]
80	Mute Triangle [EXC5]	Mute Triangle [EXC5]	Mute Triangle [EXC5]	Mute Triangle [EXC5]
81	Open Triangle [EXC5]	Open Triangle [EXC5]	Open Triangle [EXC5]	Open Triangle [EXC5]
82	Shaker	Shaker	Shaker	Shaker
83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
C6 84	Bar Chimes	Bar Chimes	Bar Chimes	Bar Chimes
85	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo [EXC6]	Mute Surdo [EXC6]	Mute Surdo [EXC6]	Mute Surdo [EXC6]
87	Open Surdo [EXC6]	Open Surdo [EXC6]	Open Surdo [EXC6]	Open Surdo [EXC6]
88	-----	-----	-----	Applause

* ----- : No sound.

* [EXC]: will not sound simultaneously with other percussion instruments of the same number.

SFX Set

	27	-----
28		-----

29	30	-----
31		-----
	32	-----
33		-----
	34	-----
35		-----
C2	36	-----
	37	-----
	38	-----
	39	High Q
	40	Slap
		Scratch Push [EXC7]
	41	Scratch Pull [EXC7]
	42	Sticks
	43	Square Click
	44	Metronome Click
C3	45	Metronome Bell
	46	Guitar Fret Noise
	47	
	48	Guitar Cutting Noise Up
	49	Guitar Cutting Noise Down
	50	String Slap of Double Bass
	51	Fl.Key Click
	52	Laughing
		Screaming
	53	Punch
C4	54	Heart Beat
	55	Footsteps 1
	56	Footsteps 2
	57	Applause
	58	Door Creaking
	59	
	60	Door
	61	Scratch
	62	Wind Chimes
	63	Car-Engine
C5	64	Car-Stop
		Car-Pass
	65	Car-Crash
	66	Siren
	67	Train
	68	Jet Plane
	69	Helicopter
	70	Starship
	71	
	72	Gun Shot
C6	73	Machine Gun
	74	Laser Gun
	75	Explosion
	76	Dog
		Horse-Gallop
	77	Birds
	78	Rain
	79	Thunder
	80	Wind
	81	Seashore
C6	82	Stream
	83	Bubble
	84	
	85	-----
	86	-----

	87	-----
	88	-----

* ----- : No sound.

* [EXC]: will not sound simultaneously with other percussion instruments of the same number.

Internal Song List

1	La Fille aux Cheveux de Lin
2	La Campanella
3	Trio Grande
4	Wedding Song
5	Scherzo No.2
6	Étude, op.10-12
7	Sonate No.15
8	Liebesträume 3
9	Étude, op.10-3
10	Je te veux
11	Valse, op.64-1
12	Golliwog's Cakewalk
13	Fantaisie-Impromptu
14	Arabesque 1
15	An der schönen, blauen Donau
16	Auf Flügeln des Gesanges
17	Mazurka No.5
18	Gymnopédie 1
19	Étude, op.25-1
20	Clair de Lune
21	Étude, op.10-5
22	Dr. Gradus ad Parnassum
23	Grande Valse Brillante
24	La prière d'une Vierge
25	Course en Troïka
26	To The Spring
27	Valse, op.64-2
28	Radetzky Marsch
29	Träumerei
30	Moments Musicaux 3
31	Prélude, op.28-15
32	Harmonious Blacksmith
33	Ungarische Tänze 5
34	Türkischer Marsch (Beethoven)
35	Nocturne No.2

36	Frühlingslied
37	Präludium
38	Jägerlied
39	Menuet Antique
40	Für Elise
41	Türkischer Marsch (Mozart)
42	Ständchen
43	Humoreske
44	Blumenlied
45	Alpenglöckchen
46	Menuett G dur (Beethoven)
47	Venezianisches Gondellied
48	Alpenabendröte
49	Farewell to the Piano
50	Brautchor
51	Battle of Waterloo
52	Wiener Marsch
53	Le Coucou
54	Menuett G dur (Bach)
55	Spinnerlied
56	Gavotte
57	Heidenröslein
58	Zigeuner Tanz
59	La Cinquantaine
60	Csikos Post
61	Dolly's Dreaming Awakening
62	La Violette
63	Fröhlicher Landmann
64	Sonatine op.36-1 (Clementi)
65	Sonatine op.20-1 (Kuhlau)
66	Sonatine No.5 (Beethoven)
67	Late Night Chopin
68	Fly Flee
69	Leveil de lamour
70	Preludelight

* All rights reserved. Unauthorized use of this material for purposes other than private, personal enjoyment is a violation of applicable laws.

* No data for the music that is played will be output from MIDI OUT.

Parameters Stored in Memory Backup

Piano Designer Settings	Open/close lid	p. 28
	Key Touch	p. 28, p. 30
	Key Touch Offset	p. 28
	Hammer Response	p. 28
	Hammer Noise	p. 28
	Master Tuning	p. 28, p. 77
	Temperament (Temperament, Tonic)	p. 28
	Stretch Tuning	p. 28
	Damper Resonance	p. 28
	Damper Noise	p. 28
	Duplex Scale	p. 28
	String Resonance	p. 28
	Key Off Resonance	p. 28
Function Mode Settings	Equalizer (On/Off, Parameter Settings)	p. 78
	Play Mode	p. 79
	Metronome Sound	p. 80
	Countdown Sound	p. 80
	Transpose Mode	p. 81
	Damper Pedal Part	p. 81
	3D Mode	p. 84
	Track Assign	p. 85
	Lyrics	p. 85
	Language	p. 85
Other Settings	3D Sound Control (On/Off, Depth)	p. 31
	Dynamics Sound Control (Type)	p. 32
	Reverb (On/Off, Depth)	p. 33
	Dual Balance	p. 42
	Split Point	p. 45
	Twin Piano Mode	p. 39
Settings stored immediately, whenever a change is made (Memory Backup procedure not needed)	USB Driver Setting	p. 84
	Ext. Memory Mode	p. 84

Music Files That the HP207 Can Use

What Are Music Files?

Music files contain musical information such as how long the key for a corresponding pitch is played, the force applied to the key played, and other such information. When the performance data (music file) is sent by your computer or similar device, the song will be played exactly as specified by the data. This is different than a audio CD, since the music file does not contain a recording of the sound itself. This makes it possible to change tempos and keys freely, allowing you to use it in many different ways.

Regarding Copyright

Use of the song data supplied with the CD-ROM attached to this product for any purpose other than private, personal enjoyment without the permission of the copyright holder is prohibited by law. Additionally, this data must not be copied, nor used in a secondary copyrighted work without the permission of the copyright holder.

Please be aware that if you create derivative works that are based on existing copyrighted material, such as commercially available SMF music files, such works may violate copyright law if used for any purpose other than personal enjoyment. Roland takes no responsibility for any copyright violation you may commit by creating such works.

The HP207 Allows You To Use the Following Music Files

VIMA TUNES

VIMA TUNES is a Roland specification for music files that contains image and lyric data, allowing you to enjoy songs with lyrics and images simultaneously. When data bearing the "VIMA TUNES" logo is played back on a device that bears the same logo, lyrics can be shown on the screen of a connected external display or television, letting you enjoy karaoke or watch a slide show.

* This instrument (HP207) is not able to play back VIMA TUNES images.

SMF Music Files

SMFs (Standard MIDI Files) use a standard format for music file that was formulated so that files containing music file could be widely compatible, regardless of the manufacturer of the listening device. An enormous variety of music is available, whether it be for listening, for practicing musical instruments, for Karaoke, etc.

SMF with Lyrics

"SMF with Lyrics" refers to SMF (Standard MIDI File) that contains the lyrics. When Music Files carrying the "SMF with Lyrics" logo are played back on a compatible device (one bearing the same logo), the lyrics will appear in its display. The HP207 come equipped with GM 2/GS sound generators.

General MIDI



The General MIDI is a set of recommendations which seeks to provide a way to go beyond the limitations of proprietary designs, and standardize the MIDI capabilities of sound generating devices. Sound generating devices and music files that meets the General MIDI standard bears the General MIDI logo. Music files bearing the General MIDI logo can be played back using any General MIDI sound generating unit to produce essentially the same musical performance.

General MIDI 2



The upwardly compatible General MIDI 2 recommendations pick up where the original General MIDI left off, offering enhanced expressive capabilities, and even greater compatibility. Issues that were not covered by the original General MIDI recommendations, such as how sounds are to be edited, and how effects should be handled, have now been precisely defined. Moreover, the available sounds have been expanded. General MIDI 2 compliant sound generators are capable of reliably playing back music files that carry either the General MIDI or General MIDI 2 logo.

In some cases, the conventional form of General MIDI, which does not include the new enhancements, is referred to as "General MIDI 1" as a way of distinguishing it from General MIDI 2.

GS Format



The GS Format is Roland's set of specifications for standardizing the performance of sound generating devices. In addition to including support for everything defined by the General MIDI, the highly compatible GS Format additionally offers an expanded number of sounds, provides for the editing of sounds, and spells out many details for a wide range of extra features, including effects such as reverb and chorus. Designed with the future in mind, the GS Format can readily include new sounds and support new hardware features when they arrive. Since it is upwardly compatible with the General MIDI, Roland's GS Format is capable of reliably playing back GM Scores equally as well as it performs GS music files (music files that have been created with the GS Format in mind).

XG lite



XG is a tone generator format of YAMAHA Corporation, that defines the ways in which voices are expanded or edited and the structure and type of effects, in addition to the General MIDI 1 specification. XGlite is a simplified version of XG tone generation format. You can play back any XG music files using an XGlite tone generator. However, keep in mind that some music files may play back differently compared to the original files, due to the reduced set of control parameters and effects.

MIDI Implementation Chart

Function...		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1 1-16	1-16 1-16	
Mode	Default Messages Altered	Mode 3 x *****	Mode 3 Mode 3, 4 (M=1)	* 2
Note Number :	True Voice	15-113, 119-127 *****	0-127 0-127	
Velocity	Note ON Note OFF	O O	O O	
After Touch	Key's Ch's	x x	O O	*1 *1
Pitch Bend		x	O	
Control Change	0, 32	O	O	*1 Bank select
	1	x	O	*1 Modulation
	5	x	O	*1 Portamento time
	6, 38	x	O	*1 Data entry
	7	x	O	*1 Volume
	10	x	O	*1 Panpot
	11	x	O	*1 Expression
	64	O	O	*1 Hold 1
	65	x	O	*1 Portamento
	66	O	O	*1 Sostenuto
	67	O	O	*1 Soft
	84	x	O	Portamento control
	91	O	O (Reverb)	Effect1 depth
	93	x	O (Chorus)	Effect3 depth
	98, 99	x	O	*1 NRPN LSB, MSB
	100, 101	x	O	*1 RPN LSB, MSB
Prog Change	: True #	0-127 *****	O 0-127	Program number 1-128
System Exclusive		O	O	
System Common	: Song Pos : Song Sel : Tune	x x x	x x x	
System Real Time	: Clock : Commands	O O	x x	
Aux Message	: All sound off : Reset all controllers : Local Control : All Notes OFF : Active Sense : Reset	x x x x O x	O (120, 126, 127) O O O (123-125) O x	
Notes		* 1 O x is selectable by Sys Ex. * 2 Recognized as M=1 even if M≠1.		

Mode 1 : OMNI ON, POLY Mode 2 : OMNI ON, MONO
Mode 3 : OMNI OFF, POLY Mode 4 : OMNI OFF, MONO

O : Yes
X : No

Main Specifications

HP207: Digital Piano

<Keyboard>	
Keyboard	88 keys (PHA II ivory feel Keyboard with Escapement)
Touch Sensitivity	Touch: 100 levels / Fixed Touch (level adjustable)
	Hammer Response: Off / 1–10
Keyboard Mode	Whole, Dual (volume balance adjustable), Split (split point adjustable), Twin piano
<Sound Generator> Conforms to GM2/GS/XG Lite	
Max. Polyphony	128 voices
Tones	337 tones (including 8 drum sets, 1 SFX set)
Temperament	8 types, selectable tonic
Stretched Tuning	Off/Preset/User tuning (adjustable in individual notes: -50.0– +50.0 cent)
Master Tuning	415.3–466.2 Hz (adjustable in increments of 0.1 Hz)
Transpose	Key Transpose: -6–+5 (in semitones)
	Playback Transpose (with Audio CD/Audio File): -6–+5 (in semitones)
Effects	3D (4 Levels), Dynamics (4 types), Reverb (Off/1–10), Rotary Speaker Effect (only for organ tones, Slow/Fast), 4-band Digital Equalizer, Tone effects (only adjust values)
	Only for Piano Tones: Open/close lid (only for piano tones, 7 levels), Hammer Noise (5 levels), Damper Resonance (Off/1–10), Damper Noise (Off/1–10), Duplex Scale (Off/1–10), String Resonance (Off/1–10), Key Off Resonance (Off/1–10)
<Recorder>	
Tracks	3 tracks
Songs	Recorder section: 1 song Internal Memory: Max. 99 songs
Note Storage	Approx. 30,000 notes
Control	Song Select, Play/Stop, Rec, Previous/Rewinding, Next/Fast-forwarding, Track Mute (Mute Level adjustable), Tempo, Tempo Mute, All Song Play, Count-in, Count-down, 16 part Mute, Song Volume
	Center Cancel (only for audio playback)
Tempo	Quarter note = 10 to 500
Resolution	120 ticks per quarter note
Metronome	Beat: 2/2, 0/4, 2/4, 3/4, 4/4, 5/4, 6/4, 7/4, 3/8, 6/8, 9/8, 12/8
	Volume: 0–10 levels
	Metronome Pattern: 11 patterns
	Metronome Sound: 8 types

<Internal Memory>	
Songs	Max. 99 songs
Save Song	Standard MIDI Files (Format 0)
<External Memory>	
External Storage	USB CD Drive (Sold Commercially ^{*1} , Read Only) USB Flash Memory (Sold Separately) USB Floppy Disk Drive (Sold Separately)
Playable Software	Standard MIDI Files (Format 0/1), Roland Original Format (i-Format), Audio File (WAV 44.1kHz / 16bit Linear Format) Audio CDs (CD-DA)
<Others>	
Internal Songs	70 songs + 7 Tone Demo Songs
Rated Power Output	60 W x 2
Speakers	16 cm x 2, 5 cm x 2
Display	128 x 64 dots Graphic monochrome LCD (with backlit)
Language	English, Japanese
Lyrics	Yes (Built-in Display)
Control	Volume, Brilliance, LCD Contrast
Pedal	Damper (half-pedal recognition), Soft (half-pedal recognition, function assignable), Sostenuuto (function assignable)
Other Function	Panel Lock, Panel Lid, V-LINK
Connectors	AC inlet, Pedal connector, Input jacks (Front: L/Mono, R Rear: L/Mono, R), Output jacks (L/Mono, R), USB (MIDI) connector, MIDI connectors (IN, OUT), Phones jack (Stereo) x 2, Ext Memory port
Power Supply	AC 115 V, AC 117 V, AC 220 V, AC 230 V, AC 240 V (50/60 Hz)
Power Consumption	105 W
Dimensions	1388 (W) x 529 (D) x 1076 (H) mm (with Music Rest) 54-11/16 (W) x 20-7/8 (D) x 42-3/8 (H) inches 1388 (W) x 529 (D) x 892 (H) mm (without Music Rest) 54-11/16 (W) x 20-7/8 (D) x 35-1/8 (H) inches
Weight	78 kg / 172 lbs
Accessories	Owner's Manual, Power Cord, Roland 60 Classical Piano Masterpieces, Headphones Hook
Options	USB Memory, Floppy Disk Drive, CD Drive Holder

^{*1} A list of the CD drives that have been tested and found to be compatible is available on the Roland website.
<http://www.roland.com/>

NOTE In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

INDEX

Numerics

[3D] button	31
3D Mode	84
3D Sound Control	31

A

AC inlet	14, 16
[Accomp] button	52, 64
Adjuster	20
Adjusting	
Keyboard Sensitivity	30
All Song Play	50

B

Balance	
Volume	42
Beat	
Metronome	47
Bottom Panel	14–15
Brightness	
Display	19

C

CD	22
Center Cancel	56
Center/Left Pedal Func	81
Composer MIDI Out	82
Computer	91
Connecting	
Audio Equipment	88
CD drive	22
Computer	91
MIDI devices	90
Pedal cord	16
Power cord	16
Speaker cable	16
Speakers	88
USB memory	22
Copying	69, 74
Countdown	80
Countdown Part	80
Countdown Sound	80
Count-In	47

D

Damper Noise	28
Damper pedal	20
Damper Resonance	28
Damper/Center/Left Pedal Part	81
Deleting	
Saved Song	72
Demo songs	23
Display	13
Brightness	19
[DISPLAY BRIGHTNESS] knob	19
[Display Contrast] knob	13
Dual Play	40
Duplex Scale	28–29
Dynamics Sound Control	32

E

Editing	
Effect Settings	34
Effects	34
Reverb	33
Rotary	35
[Effects] button	34
Equalizer	78
Erasing	
Recorded Performance	66
Error Messages	96
Ext. Memory Mode	84
External Memory connector	15, 22

F

Factory Reset	86
Fast-forward	49
Fix Velocity	81
Floppy Disk Drive	22
[►►] button	13
Front Panel	12
Function Mode	76

G

General MIDI	106
General MIDI 2	106
GS Format	106

H

Hammer Noise	28
Hammer Response	28
Headphones	21

I

Initializing	
Memory	67
Input jack	14–15
Internal Memory	69
Internal Song List	104

K

Key	36, 55
Key Off Resonance	28
Key Touch	28, 30, 81
[Key Touch] button	30
Key Touch Offset	28
Key Transpose	36
Keyboard Settings	81

L

Language	85
Layering	40
[Left] button	52, 60, 64
Lid	17, 28

List	
Error Messages	96
Internal Song	104
Parameters	105
Tones	97
Troubleshooting	92
Local Control	82
Local Off	82
Local On	82
Locking	
Panel	87
Lyrics	85

M

Master Gain	84
Master Tuning	28, 77
Memory Backup	86
Metronome	46, 80
[Metronome] button	46
Metronome Pattern	80
Metronome Sound	80
MIDI	82, 90
MIDI connector	91
MIDI Out/In connector	15
MIDI Transmit Ch.	82
Music Files	106
Music Rest	17
Muting	
Part Volume	53
Tempo	54

N

Noise	28
-------	----

O

Octave Shift	81
Opening/Closing	
Lid	17
Output jack	14

P

Panel Lock	87
Parameters	105
Part Mute	79
Pedal	20, 81
Pedal connector	14, 16
Pedal cord	16
Phones jack	15, 21
Piano Designer	27, 29
Demo Songs	25
[Piano Designer] button	27
Pitch	36, 77
Play Mode	50
[▶/■] button	13
Playback Transpose	55
Playing	
Song	48
Power	18
Power cord	16
[Power] switch	12, 16, 18

R

[●] button	13, 58, 61
Recommended Tone	85
Recording	57
Additional Part	61
Along with a Song	63
For Each Hand	60
New Song	58
Restoring	
Settings	86
[Reverb] button	33
Reverb Effect	33
Rewind	49
[◀◀] button	13
[Right] button	52, 60, 64
Rotary Effect	35

S

Saving	67, 69
Piano Designer Settings	29
Recorded Song	70
Selecting	
Song	48
Sounds	26
Tones	41, 44
Sensitivity	30
Settings	76
Equalizer	78
Keyboard	81
Metronome	80
MIDI	82
Pedal	81
Remembering	86
Song Playback	79
Tuning	77
USB Driver	84
SMF	85
SMF Music Files	106
SMF with Lyrics	106
Soft pedal	20
Song	
All Song Play	50
[Song] button	48
Song Name	70
Songs	48
Demo	23
Sostenuto pedal	20
Sounds	
Selecting	26
Speaker cable	16
Speaker connector	16
Specifications	108
[Split] button	43
Split Play	43
Split Point	43, 45
Standard Pitch	77
Stretched Tuning	28
String Resonance	28
System Settings	76

INDEX

T

Temperament	28
Tempo	
Metronome	46
Tempo Mute	54
[Tempo/Beat] button	47
Tone button	12, 26
Tone Demo songs	23
Tone List	97
Tones	44
Layering	40
Tonic	28
Track Assign	85
Track button	13, 52, 60, 64, 85
Transpose	36, 55
[Transpose] button	36, 55
Transpose Mode	81
Troubleshooting	92
Tuning	28, 77
Twin Piano	38
[Twin Piano] button	39
Twin Piano mode	39

U

USB connector	15, 91
USB Driver	84
USB Memory	69
USB memory	22

V

VIMA TUNES	85, 106
V-LINK	83
Volume	19
Audio File	53
Dual Play	42
Headphones	19
Master Gain	84
Metronome	47
Music CD	53
Muting	53
Song	53
Volume Balance	42
[Volume] knob	12, 19

X

XG lite	106
---------------	-----

MEMO

MEMO



This product complies with the requirements of European Directives EMC 89/336/EEC and LVD 73/23/EEC.

For EU Countries

FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Unauthorized changes or modification to this system can void the users authority to operate this equipment.
This equipment requires shielded interface cables in order to meet FCC class B Limit.

For the USA

NOTICE

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

AVIS

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

For Canada

DECLARATION OF CONFORMITY Compliance Information Statement

Model Name : HP207
Type of Equipment : Digital Piano
Responsible Party : Roland Corporation U.S.
Address : 5100 S. Eastern Avenue, Los Angeles, CA 90040-2938
Telephone : (323) 890-3700

For the USA



This product must be disposed of separately
at your local waste recycling centre.
Do not dispose of in household waste bin.

Information

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.

AFRICA

EGYPT

Al Fanny Trading Office
9, EBN Hagar A1 Askalany
Street,
ARD El Golf, Heliopolis,
Cairo 11341, EGYPT
TEL: 20-2-417-1828

REUNION

Maison FO - YAM Marcel
25 Rue Jules Hermann,
Chaudron - BP79 97 491
Ste Clotilde Cedex,
REUNION ISLAND
TEL: (0262) 218-429

SOUTH AFRICA

T.O.M.S. Sound & Music
(Pty)Ltd.
2 ASTRON ROAD DENVER
JOHANNESBURG ZA 2195,
SOUTH AFRICA
TEL: (011)417 3400
FAX: (011)417 3462

Paul Bothner(PTY)Ltd.
Royal Cape Park, Unit 24
Londonderry Road, Ottery 7800
Cape Town, SOUTH AFRICA
TEL: (021) 799 4900

ASIA

CHINA

Roland Shanghai Electronics
Co.,Ltd.
5F, No.1500 Pingliang Road
Shanghai 200090, CHINA
TEL: (021) 5580-0800

Roland Shanghai Electronics
Co.,Ltd.
(BEIJING OFFICE)
10F, No.18 3 Section Anhuaxili
Chaoyang District Beijing
100011 CHINA
TEL: (010) 6426-5050

HONG KONG

Tom Lee Music Co., Ltd.
Service Division
22-32 Pun Shan Street, Tsuen
Wan, New Territories,
HONG KONG
TEL: 2415 0911

Parsons Music Ltd.
8th Floor, Railway Plaza, 39
Chatham Road South, T.S.T,
Kowloon, HONG KONG
TEL: 2333 1863

INDIA

Rivera Digitec (India) Pvt. Ltd.
409, Nirman Kendra
Mahalaxmi Flats Compound
Off. Dr. Edwin Moses Road,
Mumbai-400011, INDIA
TEL: (022) 2493 9051

INDONESIA

PT Citra IntiRama
Jl. Cideng Timur No. 15J-150
Jakarta Pusat
INDONESIA
TEL: (021) 6324170

KOREA

Cosmos Corporation
1461-9, Seocho-Dong,
Seocho Ku, Seoul, KOREA
TEL: (02) 3486-8855

MALAYSIA

Roland Asia Pacific Sdn. Bhd.
45-1, Block C2, Jalan PJU 1/39,
Dataran Prima, 47301 Petaling
Jaya, Selangor, MALAYSIA
TEL: (03) 7805-3263

PHILIPPINES

G.A. Yupangco & Co. Inc.
339 Gil J. Puyat Avenue
Makati, Metro Manila 1200,
PHILIPPINES
TEL: (02) 899 9801

SINGAPORE

SWEE LEE MUSIC
COMPANY PTE. LTD.
150 Sims Drive,
SINGAPORE 387381
TEL: 6846-3676

TAIWAN

ROLAND TAIWAN
ENTERPRISE CO., LTD.
Room 5, 9fl. No. 112 Chung
Shan N.Road Sec.2, Taipei,
TAIWAN, R.O.C.
TEL: (02) 2561 3339

THAILAND

Theera Music Co., Ltd.
330 Soi Verg NakornKasem,
New Road, Sumpantawongse,
Bangkok 10100, THAILAND
TEL: (02) 224-8821

AUSTRALIA/ NEW ZEALAND

AUSTRALIA/
NEW ZEALAND
Roland Corporation
Australia Pty.,Ltd.
38 Campbell Avenue
Dee Why West. NSW 2099
AUSTRALIA

For Australia
Tel: (02) 9982 8266
For New Zealand
Tel: (09) 3098 715

CENTRAL/LATIN AMERICA

ARGENTINA

Instrumentos Musicales S.A.
Av. Santa Fe 2055
(1123) Buenos Aires
ARGENTINA
TEL: (011) 4508-2700

BARBADOS

A&B Music Supplies LTD
12 Webster Industrial Park
Wilkey, St.Michael, Barbados
TEL: (246)430-1100

BRAZIL

Roland Brasil Ltda.
Rua San Jose, 780 Sala B
Parque Industrial San Jose
Cotia - Sao Paulo - SP, BRAZIL
TEL: (011) 4615 5666

CHILE

Comercial Fancy II S.A.
Rut.: 96.919.420-1
Nataliel Cox #739, 4th Floor
Santiago - Centro, CHILE
TEL: (02) 688-9540

COLOMBIA

Centro Musical Ltda.
Cra 43 B No 25 A 41 Bododega 9
Medellin, Colombia
TEL: (574)3812529

COSTA RICA

JUAN Bansbach Instrumentos
Musicales
Ave.1. Calle 11, Apartado
10237,
San Jose, COSTA RICA
TEL: 258-0211

CURACAO

Zeelandia Music Center Inc.
Orionweg 30
Curacao, Netherland Antilles
TEL:(305)5926866

DOMINICAN REPUBLIC

Instrumentos Fernando Giraldez
Calle Proyecto Central No.3
Ens.La Esperilla
Santo Domingo,
Dominican Republic
TEL:(809) 683 0305

ECUADOR

Mas Musica
Rumichaca 822 y Zaruma
Guayaquil - Ecuador
TEL:(593-4)2302364

EL SALVADOR

OMNI MUSIC
75 Avenida Norte y Final
Alameda Juan Pablo II,
Edificio No.4010 San Salvador,
EL SALVADOR
TEL: 262-0788

GUATEMALA

Casa Instrumental
Calzada Roosevelt 34-01,zona 11
Ciudad de Guatemala
Guatemala
TEL:(502) 599-2888

HONDURAS

Almacen Pajaro Azul S.A. de C.V.
BO.Paz Barahona
3 Ave.11 Calle S.O
San Pedro Sula, Honduras
TEL: (504) 553-2029

MARTINIQUE

Musique & Son
Z.L.Les Mangle
97232 Le Lamantin
Martinique F.W.I.
TEL: 596 596 426860

Gigamusic SARL
10 Rte De La Folie
97200 Fort De France
Martinique F.W.I.
TEL: 596 596 715222

MEXICO

Casa Veerkamp, s.a. de c.v.
Av. Toluca No. 323, Col. Olivar
de los Padres 01780 Mexico
D.F. MEXICO
TEL: (55) 5668-6699

NICARAGUA

Bansbach Instrumentos
Musicales Nicaragua
Altamira D'Este Calle Principal
de la Farmacia 5ta.Avenida
1 Cuadra al Lago.#503
Managua, Nicaragua
TEL: (505)277-2557

PANAMA

SUPRO MUNDIAL, S.A.
Boulevard Andrews, Albrook,
Panama City, REP. DE
PANAMA
TEL: 315-0101

PARAGUAY

Distribuidora De
Instrumentos Musicales
J.E. Olear y ESQ. Manduvira
Asuncion PARAGUAY
TEL: (595) 21 492147

PERU

Audionet
Distribuciones Musicales SAC
Juan Fanning 530
Miraflores
Lima - Peru
TEL: (511) 4461388

TRINIDAD

AMR Ltd
Ground Floor
Maritime Plaza
Barataria Trinidad W.I.
TEL: (868) 638 6385

URUGUAY

Todo Musica S.A.
Francisco Acuna de Figueroa
1771
C.P.: 11.800
Montevideo, URUGUAY
TEL: (02) 924-2335

VENEZUELA

Instrumentos Musicales
Allegro,C.A.
Av.las industrias edf.Guitar
import
#7 zona Industrial de Turumo
Caracas, Venezuela
TEL: (212) 244-1122

EUROPE

AUSTRIA

Roland Elektronische
Musikinstrumente HmbH.
Austrian Office
Eduard-Bodem-Gasse 8,
A-6020 Innsbruck, AUSTRIA
TEL: (0512) 26 44 260

BELGIUM/FRANCE/

HOLLAND/
LUXEMBOURG
Roland Central Europe N.V.
Houtstraat 3, B-2260, Oevel
(Westerlo) BELGIUM
TEL: (014) 575811

CROATIA

ART-CENTAR
Degenova 3,
HR - 10000 Zagreb
TEL: (1) 466 8493

CZECH REP.

CZECH REPUBLIC
DISTRIBUTOR s.r.o
Votárova 247/16
CZ - 180 00 PRAHA 8,
CZECH REP.
TEL: (2) 830 20270

DENMARK

Roland Scandinavia A/S
Nordhavnsvej 7, Postbox 880,
DK-2100 Copenhagen
DENMARK
TEL: 3916 6200

FINLAND

Roland Scandinavia As, Filial
Finland
Elannontie 5
FIN-01510 Vantaa, FINLAND
TEL: (019) 68 24 020

GERMANY

Roland Elektronische
Musikinstrumente HmbH.
Oststrasse 96, 22844
Norderstedt, GERMANY
TEL: (040) 52 60090

GREECE/CYPRUS

STOLLAS S.A.
Music Sound Light
155, New National Road
Patras 26442, GREECE
TEL: 2610 435400

HUNGARY

Roland East Europe Ltd.
Warehouse Area 'DEPO' Pf.83
H-2046 Torokbalint,
HUNGARY
TEL: (23) 511011

IRELAND

Roland Ireland
G2 Calmount Park, Calmount
Avenue, Dublin 12
Republic of IRELAND
TEL: (01) 4294444

ITALY

Roland Italy S. p. A.
Viale delle Industrie 8,
20020 Arese, Milano, ITALY
TEL: (02) 937-78300

NORWAY

Roland Scandinavia Avd.
Kontor Norge
Lilleakerveien 2 Postboks 95
Lilleaker N-0216 Oslo
NORWAY
TEL: 2273 0074

POLAND

ROLAND POLSKA SP. Z O.O.
UL. Gibraltarska 4.
PL-03 664 Warszawa
POLAND
TEL: (022) 679 4419

PORTUGAL

Roland Iberia, S.L.
Portugal Office
Cais das Pedras, 8/9-1 Dto
4050-465, Porto, PORTUGAL
TEL: 22 608 00 60

ROMANIA

FBS LINES
Piata Libertatii 1,
535500 Gheorgheni,
ROMANIA
TEL: (266) 364 609

RUSSIA

MuTek
Dorozhnaya ul.3,korp.6
117 545 Moscow, RUSSIA
TEL: (095) 981-4967

SLOVAKIA

DAN Acoustic s.r.o.
Povazská 18,
SK - 940 01 Nové Zámky
TEL: (035) 6424 330

SPAIN

Roland Iberia, S.L.
Paseo García Faria, 33-35
08005 Barcelona SPAIN
TEL: 93 493 91 00

SWEDEN

Roland Scandinavia A/S
SWEDISH SALES OFFICE
Danvik Center 28, 2 tr.
S-131 30 Nacka SWEDEN
TEL: (0)8 702 00 20

SWITZERLAND

Roland (Switzerland) AG
Landstrasse 5, Postfach,
CH-4452 Itingen,
SWITZERLAND
TEL: (061) 927-8383

UKRAINE

EURHYTHMICS Ltd.
P.O.Box: 37-a.
Nedecey Str. 30
UA - 89600 Mukachevo,
UKRAINE
TEL: (03131) 414-40

UNITED KINGDOM

Roland (U.K.) Ltd.
Atlantic Close, Swansea
Enterprise Park, SWANSEA
SA7 9FJ,
UNITED KINGDOM
TEL: (01792) 702701

MIDDLE EAST

BAHRAIN

Moon Stores
No.16, Bab Al Bahrain Avenue,
P.O.Box 247, Manama 304,
State of BAHRAIN
TEL: 17 211 005

IRAN

MOCO INC.
No.41 Nike St., Dr.Shariyati Ave.,
Roberoye Cerahe Mirdamad
Tehran, IRAN
TEL: (021) 285-4169

ISRAEL

Halilit P. Greenspoon & Sons
Ltd.
8 Retziv Ha'aliya Hashnya St.
Tel-Aviv-Yafa ISRAEL
TEL: (03) 6823666

JORDAN

MUSIC HOUSE CO. LTD.
FREDDY FOR MUSIC
P. O. Box 922846
Amman 11192 JORDAN
TEL: (06) 5692696

KUWAIT

EASA HUSAIN AL-YOUSIFI
& SONS CO.
Abdullah Salem Street,
Safat, KUWAIT
TEL: 243-6399

LEBANON

Chahine S.A.L.
Gerge Zeidan St., Chahine
Bldg., Achrafieh, P.O.Box: 16-
5857
Beirut, LEBANON
TEL: (01) 20-1441

OMAN

TALENTZ CENTRE L.L.C.
Malatan House No.1
Al Noor Street, Ruwi
SULTANATE OF OMAN
TEL: 2478 3443

QATAR

Al Emadi Co. (Badie Studio &
Stores)
P.O. Box 62, Doha, QATAR
TEL: 4423-554

SAUDI ARABIA

aDawlah Universal
Electronics APL
Corniche Road, Aldossary
Bldg., 1st Floor, Alkhobar,
SAUDI ARABIA

P.O.Box 2154, Alkhobar 31952
SAUDI ARABIA
TEL: (03) 898 2081

SYRIA

Technical Light & Sound
Center
Rawda, Abdul Qader Zajzari St.
Bldg. No. 21, P.O.BOX 13520,
Damascus, SYRIA
TEL: (011) 223-5384

TURKEY

ZUHAL DIS TICARET A.S.
Galip Dede Cad. No.37
Beyoglu - Istanbul / TURKEY
TEL: (0212) 249 85 10

U.A.E.

Zak Electronics & Musical
Instruments Co. L.L.C.
Zabeel Road, Al Sherooq Bldg.,
No. 14, Grand Floor, Dubai,
U.A.E.
TEL: (04) 3360715

NORTH AMERICA

CANADA

Roland Canada Ltd.
(Head Office)
5480 Parkwood Way
Richmond B. C., V6V 2M4
CANADA
TEL: (604) 270 6626

Roland Canada Ltd.

(Toronto Office)
170 Admiral Boulevard
Mississauga On L5T 2N6
CANADA
TEL: (905) 362 9707

U. S. A.

Roland Corporation U.S.
5100 S. Eastern Avenue
Los Angeles, CA 90040-2938,
U. S. A.
TEL: (323) 890 3700

Roland®



* 0 4 4 5 2 6 3 4 - 0 2 *

04452634

07-01-2N